

A R SYSTEMS

Model No	Codes	Notes
ALL	0065 0584 0402	

ACCENT

Model No	Codes	Notes
ALL	0037 0065 0584	

ACCUPHASE

Model No	Codes	Notes
ALL	0584	
ALL	0652	V4 or Higher RCU Required
ALL	1937	V6 or Higher RCU Required
R35F18	0652	V4 ONLY RCU

ACEC

Model No	Codes	Notes
ALL	0040	

ACOUSTIC RESEARCH

Model No	Codes	Notes
ALL	1324	

ACURA

Model No	Codes	Notes
ALL	0037	

ADCOM

Model No	Codes	Notes
ALL	0312	

ALL	0653	NOT A V4 RCU
-----	------	--------------

ADDISON

Model No	Codes	Notes
----------	-------	-------

ALL	0681 0136	
-----	-----------	--

ADL

Model No	Codes	Notes
----------	-------	-------

ALL	1245	
-----	------	--

ADMIRAL

Model No	Codes	Notes
----------	-------	-------

ALL	0121 0241	
-----	-----------	--

ALL	0391 0446 0115 0191 0292	
-----	--------------------------	--

ADVENT

Model No	Codes	Notes
----------	-------	-------

ALL	0904	
-----	------	--

ADYSON

Model No	Codes	Notes
----------	-------	-------

ALL	0245 0244	
-----	-----------	--

AEA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

AEG

Model No	Codes	Notes
----------	-------	-------

ALL	0634	
-----	------	--

ALL	1191	
ALL	1584	V6 or Higher RCU Required
AGASHI		
Model No	Codes	Notes
ALL	0244 0292 0245	
AGB		
Model No	Codes	Notes
ALL	0103 0544	
AGEF		
Model No	Codes	Notes
ALL	0115	
AIKO		
Model No	Codes	Notes
ALL	0297 0037 0065 0584 0244 0399 0063 0461 0100 0389 0219 0292 0245	
AIM		
Model No	Codes	Notes
ALL	0065 0302 0100 0440 0584 0236	
AIWA		
Model No	Codes	Notes
ALL	1533 1932 1936 1942	V6 or Higher RCU Required
ALL	0729 0733	V4 or Higher RCU Required
ALL	0037 0039 0064 0185 0402	
RCAVT02	0733	V4 or Higher RCU Required
RCZVT03	0729	V4 or Higher RCU Required

SCAVT02	0733	V4 or Higher RCU Required
SE141	0729	V4 or Higher RCU Required
SE141K	0729	V4 or Higher RCU Required
SE1430	0733	V4 or Higher RCU Required
SE211	0729	V4 or Higher RCU Required
SE211K	0729	V4 or Higher RCU Required
SE2130	0733	V4 or Higher RCU Required
SE2130K	0733	V4 or Higher RCU Required
TVC1400	0729	V4 or Higher RCU Required
TVC1400K	0733	V4 or Higher RCU Required
TVSE141EH	0729	V4 or Higher RCU Required
TVSE141K	0729	V4 or Higher RCU Required
TVSE1430K	0733	V4 or Higher RCU Required
TVSE2130K	0733	V4 or Higher RCU Required
VXD1450	1936	V6 or Higher RCU Required
VXD2120	1936	V6 or Higher RCU Required
VXD2120K	1936	V6 or Higher RCU Required

AKAI

Model No	Codes	Notes
2102/2ST	0742	V4 or Higher RCU Required
2111T	0743	V4 or Higher RCU Required
28022ST	0742	V4 or Higher RCU Required
28082ST	0742	V4 or Higher RCU Required
33052ST	0742	V4 or Higher RCU Required
7RZ206C3	0742	V4 or Higher RCU Required
AKTV2020	0508	
ALL	0736	V4 or Higher RCU Required
ALL	0335 0476 0322 0440	
ALL	1936	V6 or Higher RCU Required
ALL	0724 0742 0743	V4 or Higher RCU Required
ALL	0831 0730 0206 1065 1936 0840 1287	

ALL	0236 0544 0630 0065 0659 0508 0379 0609 0100 0103 0516 0246 0245 0244 0191 0292 0576 0219 0063 0461 0584 0399 0037 0389 0574 0297 0312 0405 0634 0501	
CT2158	0236	
CT2829NUK	0191	
CTCE2125UK	0584	
DPW4200	0736	V4 ONLY RCU
NR2111T	0743	V4 or Higher RCU Required
RCDP4201	0736	V4 ONLY RCU
TV2111T	0743	V4 or Higher RCU Required

AKASHI

Model No	Codes	Notes
ALL	0037	

AKIBA

Model No	Codes	Notes
ALL	0246 0310 0065 0584 0322	

AKIRA

Model No	Codes	Notes
ALL	0446	
ALL	0218	

AKITO

Model No	Codes	Notes
ALL	0300 0065 0584	
CW1420R	0065	

AKURA

Model No	Codes	Notes
1030	0696	V4 or Higher RCU Required

AB280W	0742	V4 or Higher RCU Required
AB280WS	0742	V4 or Higher RCU Required
ALL	0246 0292 0065 0440 0311 0199 0310 0387 0521 0037 0304 0584	
ALL	0386 1696	V6 or Higher RCU Required
ALL	0696 0742	V4 or Higher RCU Required
ALL	0397	
AV322WS	0065	
AVTV014	0696	V4 or Higher RCU Required

ALARON

Model No	Codes	Notes
ALL	0207 0244	

ALBA

Model No	Codes	Notes
3359	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
AK19060824229	0383	
ALL	1065 1696	
ALL	0040	
ALL	1932 1936 1963	V6 or Higher RCU Required
ALL	0696 0705 0742	V4 or Higher RCU Required
ALL	0037 0065 0246 0399 0263 0064 0446 0609 0275 0077 0515 0244 0398 0239 0459 0191 0383 0607 0584 0471 0502	
CTV3409	0696	V4 or Higher RCU Required
CTV3411	0471	
CTV3459	0696	V4 or Higher RCU Required
CTV3459AK20	0696	V4 or Higher RCU Required
CTV359	0696	V4 or Higher RCU Required
CTV4889	0065	
CTV5105	0742	V4 or Higher RCU Required
CTV5105 (SIL)	0742	V4 or Higher RCU Required

CTV5165	0742	V4 or Higher RCU Required
CTV5165 (SIL)	0742	V4 or Higher RCU Required
CTV5169	0065	
T14ECO	0705	V4 or Higher RCU Required
V48CM	0037	

ALCYON

Model No	Codes	Notes
ALL	0104 0239	

ALKOS

Model No	Codes	Notes
ALL	0063	

ALLORGAN

Model No	Codes	Notes
ALL	0322 0245	

ALLSTAR

Model No	Codes	Notes
ALL	0065 0584	

AMBASSADOR

Model No	Codes	Notes
ALL	0205	

AMPLIVISION

Model No	Codes	Notes
ALL	0245 0398	

AMSTRAD

Model No	Codes	Notes
3028N	0440	
ALL	0050 0397	
ALL	1065	
ALL	0205 0440 0065 0399 0037 0199 0461 0544 0382 0103 0390 0246 0292 0584 0609	
ALL	1932	V6 or Higher RCU Required
CTV3020N	0065	
CTV3028N	0065	
CTV3121NS	0065	
CTV3128N	0065	
TV8128N	0065	

ANAM

Model No	Codes	Notes
ALL	0065 0584 0037	

ANAM NATIONAL

Model No	Codes	Notes
ALL	0065 0584 0678	

ANDERSSON

Model No	Codes	Notes
ALL	1191	

ANGLO

Model No	Codes	Notes
ALL	0037 0292	

ANITECH

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0502 0104 0065 0292 0310 0584

ANSONIC

Model No	Codes	Notes
3796TX	0733	V4 or Higher RCU Required
3796VTX	0733	V4 or Higher RCU Required
930	0733	V4 or Higher RCU Required
ALL	0733	V4 or Higher RCU Required
ALL	1932	V6 or Higher RCU Required
ALL	0696	V4 or Higher RCU Required
ALL	0402 0040 0065 0191 0398 0037 0312 0275 0584 0132	

AOC

Model No	Codes	Notes
ALL	0037 0136 0207 0502	
ALL	1191	

AOLINGPIKE

Model No	Codes	Notes
ALL	0292 0440	

APOLLO

Model No	Codes	Notes
ALL	0501	

ARC EN CIEL

Model No	Codes	Notes
ALL	0137 0224 0226	

ARCAM

Model No	Codes	Notes
ALL	0244 0245	
ARDEM		

Model No	Codes	Notes
5R4801	0742	V4 or Higher RCU Required
70TL3NT	0742	V4 or Higher RCU Required
7RZ206C2	0742	V4 or Higher RCU Required
ALL	0742	V4 or Higher RCU Required
ALL	0661	
ALL	0514 0065 0584	
NR34NTSI	0742	V4 or Higher RCU Required
NR36M15M	0742	V4 or Higher RCU Required
NR55M10M	0742	V4 or Higher RCU Required

ARISTONA

Model No	Codes	Notes
ALL	0065 0040 0584	
ALL	0041	

ARTHUR MARTIN

Model No	Codes	Notes
ALL	0191	

ASA

Model No	Codes	Notes
ALL	0133 0132 0115 0374 0098	

ASBERG

Model No	Codes	Notes
ALL	0065 0104 0584	

ASORA

Model No	Codes	Notes
ALL	0037	

ASTRA

Model No	Codes	Notes
ALL	0065 0584	

ASUKA

Model No	Codes	Notes
ALL	0246 0245 0244 0292 0310	
ALL	1932	V6 or Higher RCU Required

ATD

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

ATLANTIC

Model No	Codes	Notes
ALL	0234 0348 0287	
ALL	0234 0244 0065 0348 0287 0584	

ATORI

Model No	Codes	Notes
ALL	0037	

AUCHAN

Model No	Codes	Notes
ALL	0191	

AUDIOSONIC

Model No	Codes	Notes
ABS6102/06C1	0743	V4 or Higher RCU Required
ALL	0037 0065 0402 0137 0584 0245 0398 0365 0292 0246 0514	
ALL	2011	
ALL	0742 0743	V4 or Higher RCU Required
KT8942TX	0743	V4 or Higher RCU Required
KT9056STX	0742	V4 or Higher RCU Required
KT9255STX	0742	V4 or Higher RCU Required

AUDIOTON

Model No	Codes	Notes
ALL	0292 0398 0514 0245	

AUDIOWORLD

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

AUSIND

Model No	Codes	Notes
ALL	0104	

AUTOVOX

Model No	Codes	Notes
ALL	0377 0245 0104 0572 0275 0115	
ALL	0364 0234	

AVP

Model No	Codes	Notes
----------	-------	-------

ALL	1932 1936	V6 or Higher RCU Required
-----	-----------	---------------------------

AWA

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0039 0064 0185 0402 0440 0065 0584 0244 0634 0245 0136 0292	
-----	---	--

AXXENT

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

ALL	0037	
-----	------	--

AXXON

Model No	Codes	Notes
----------	-------	-------

ALL	0742	V4 or Higher RCU Required
-----	------	---------------------------

AYR

Model No	Codes	Notes
----------	-------	-------

ALL	0563	
-----	------	--

B&D

Model No	Codes	Notes
----------	-------	-------

ALL	1245	
-----	------	--

B&O

Model No	Codes	Notes
----------	-------	-------

ALL	PLEASE USE BANG AND OLUFSEN CODES	
-----	-----------------------------------	--

BAIHE

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0292 0440	
-----	----------------	--

BAILE

Model No	Codes	Notes
ALL	0037 0402	
ALL	0689	V6 or Higher RCU Required

BAIRD

Model No	Codes	Notes
ALL	0033	
ALL	1224	
ALL	0137 0221 0371 0218 0220 0101 0236 0100 0245	
BAIRD	1932	V6 or Higher RCU Required
D6093	0371	
RRS191N	0137	
RRS5990	0236	

BANG & OLUFSEN

Model No	Codes	Notes
7423	0114	
ALL	0593 0115	
ALL	0114	
AVANTI	0593	
BEOVISION	0593	

BAOHUASHI

Model No	Codes	Notes
ALL	0292 0440	

BAOSHENG

Model No	Codes	Notes
ALL	0037	

BARCO

Model No	Codes	Notes
ALL	0444	
ALL	0191	

BASIC LINE

Model No	Codes	Notes
ALL	1065 1696	
ALL	0037 0310 0246 0065 0191 0402 0584 0245 0367	
ALL	0696	V4 or Higher RCU Required
BL1415TX	0696	V4 or Higher RCU Required
BL3743	0696	V4 or Higher RCU Required
BL3743T	0696	V4 or Higher RCU Required

BASTIDE

Model No	Codes	Notes
ALL	0245	

BAUER

Model No	Codes	Notes
ALL	0037	

BAUR

Model No	Codes	Notes
ALL	0213	
ALL	0037 0065 0389 0540 0563 0223 0572 0584 0377 0533 0038 0219	
ALL	1533 1038	V6 or Higher RCU Required

BAZIN

Model No	Codes	Notes
ALL	0245	
BEIJING		
Model No	Codes	Notes
ALL	0689	V4 or Higher RCU Required
ALL	0037 0236 0254 0292 0402 0440 0510	
BEKO		
Model No	Codes	Notes
11214T	0398	
14212	0743	V4 or Higher RCU Required
14213	0743	V4 or Higher RCU Required
14213TDS	0743	V4 or Higher RCU Required
14241	0743	V4 or Higher RCU Required
14272R	0742	V4 or Higher RCU Required
14272TDS	0742	V4 or Higher RCU Required
20212	0743	V4 or Higher RCU Required
20212R	0743	V4 or Higher RCU Required
20212RD	0743	V4 or Higher RCU Required
20212T	0743	V4 or Higher RCU Required
20242	0743	V4 or Higher RCU Required
20242R	0742	V4 or Higher RCU Required
20243	0743	V4 or Higher RCU Required
20244	0743	V4 or Higher RCU Required
20272TDS	0742	V4 or Higher RCU Required
20411	0742	V4 or Higher RCU Required
20420R	0398	
20LB450	0742	V4 or Higher RCU Required
21211	0743	V4 or Higher RCU Required
21241	0743	V4 or Higher RCU Required
21241T	0742	V4 or Higher RCU Required
21242	0743	V4 or Higher RCU Required

21411	0742	V4 or Higher RCU Required
21411ND	0742	V4 or Higher RCU Required
23416ND	0743	V4 or Higher RCU Required
25411	0742	V4 or Higher RCU Required
25411ND	0742	V4 or Higher RCU Required
27420	0514	
28411	0742	V4 or Higher RCU Required
28411ND	0742	V4 or Higher RCU Required
28412	0742	V4 or Higher RCU Required
28412ND	0742	V4 or Higher RCU Required
28416	0742	V4 or Higher RCU Required
28416NDS	0742	V4 or Higher RCU Required
28416VNDS	0742	V4 or Higher RCU Required
284216WNS	0742	V4 or Higher RCU Required
284239NS	0742	V4 or Higher RCU Required
284248WNS	0742	V4 or Higher RCU Required
28426ND	0742	V4 or Higher RCU Required
28426NDS	0742	V4 or Higher RCU Required
28T1081	0742	V4 or Higher RCU Required
29121NX	0065	
29411VNDJ	0743	V4 or Higher RCU Required
30328MX	0514	
32416	0742	V4 or Higher RCU Required
32426NDS	0742	V4 or Higher RCU Required
32426VNDS	0742	V4 or Higher RCU Required
33411	0742	V4 or Higher RCU Required
33411ND	0742	V4 or Higher RCU Required
ALL	0742 0743	V4 or Higher RCU Required
ALL	0836	
ALL	0514 0398 0065 0063 0446 0584 0634	
NR14213R	0743	V4 or Higher RCU Required
NR14272R	0742	V4 or Higher RCU Required
NR14272TDS	0742	V4 or Higher RCU Required
NR14B3M04XY	0743	V4 or Higher RCU Required

NR20212T	0743	V4 or Higher RCU Required
NR20242T	0742	V4 or Higher RCU Required
NR20272TDS	0742	V4 or Higher RCU Required
NR20420R	0398	
NR21411ND	0742	V4 or Higher RCU Required
NR28128NX	0065	
NR28411ND	0742	V4 or Higher RCU Required
NR28411TD	0742	V4 or Higher RCU Required
NR28416ND	0742	V4 or Higher RCU Required
NR284216WNS	0742	V4 or Higher RCU Required
NR284239NS	0742	V4 or Higher RCU Required
NR284248WNS	0742	V4 or Higher RCU Required
NR28426NDS	0742	V4 or Higher RCU Required
NR28B4T05N	0742	V4 or Higher RCU Required
NR32416NDS	0742	V4 or Higher RCU Required
NR32426NDS	0742	V4 or Higher RCU Required
NRT09NTSIAV	0742	V4 or Higher RCU Required
NRTS28T	0742	V4 or Higher RCU Required
RZ206/C4	0742	V4 or Higher RCU Required
TVB4216	0743	V4 or Higher RCU Required
TVB4831	0742	V4 or Higher RCU Required
TVB5130	0742	V4 or Higher RCU Required
TVB5230	0742	V4 or Higher RCU Required
TVB5635	0742	V4 or Higher RCU Required

BELL & HOWELL

Model No	Codes	Notes
ALL	0045	

BELSON

Model No	Codes	Notes
ALL	1219	

BENNETT

Model No	Codes	Notes
ALL	0065 0584	

BENQ

Model No	Codes	Notes
ALL	1240 1784	

BEON

Model No	Codes	Notes
ALL	0060	
ALL	0065 0446 0584	

BERTHEN

Model No	Codes	Notes
ALL	1696	
ALL	0696	V4 or Higher RCU Required
CTV14	0696	V4 or Higher RCU Required

BEST

Model No	Codes	Notes
ALL	0449	
ALL	0398 0365	

BESTAR

Model No	Codes	Notes
ALL	0402 0065 0398 0584	

BESTAR - DAEWOO

Model No	Codes	Notes
----------	-------	-------

ALL 0402

BINATONE

Model No Codes Notes

ALL 0245

BLACK DIAMOND

Model No Codes Notes

ALL 0584 0642

ALL 1065 1191

ALL 0065 0556

BDS2846WS 0065

BDS28WS 0556

BDS29S 0065

BLACK STAR

Model No Codes Notes

ALL 0275

BLACK STRIP

Model No Codes Notes

ALL 0063

BLACKTRON

Model No Codes Notes

ALL 0310

BLACKWAY

Model No Codes Notes

ALL 0310 0246

BLAUPUNKT

Model No	Codes	Notes
ALL	0219 0563 0223 0198 0064	
ALL	0346 0355 0241 0476 0329 0582 0228 0356	

BLUE SKY

Model No	Codes	Notes
930	0696	V4 or Higher RCU Required
ALL	1937 1962 1932 1936	V6 or Higher RCU Required
ALL	0065 0246 0584 0515 0310	
ALL	0652	
ALL	1065 1696 1219 0836	
ALL	0696 0742 0743	V4 or Higher RCU Required
B9045BK55S	0743	V4 or Higher RCU Required
BK705	0742	V4 or Higher RCU Required
BK70S	0742	V4 or Higher RCU Required
BS3366	0696	V4 or Higher RCU Required
BS36	0696	V4 or Higher RCU Required
BS3798	0696	V4 or Higher RCU Required
BS3799TX	0696	V4 or Higher RCU Required
CB3698	0652	V4 ONLY RCU
GP2110	0743	V4 or Higher RCU Required
NRBK55S	0742	V4 or Higher RCU Required
NRBK70S	0742	V4 or Higher RCU Required
NRFX70	0742	V4 or Higher RCU Required
NRFX84	0742	V4 or Higher RCU Required
NRGP21S	0743	V4 or Higher RCU Required
NRSX2810	0742	V4 or Higher RCU Required
SX2810	0742	V4 or Higher RCU Required
TK7000	0742	V4 or Higher RCU Required
TV28BSFX70	0742	V4 or Higher RCU Required

BLUE STAR

Model No	Codes	Notes
ALL	0310	

BONDSTEC

Model No	Codes	Notes
ALL	0275	

BOOTS

Model No	Codes	Notes
ALL	0245 0300 0037	

BOXLIGHT

Model No	Codes	Notes
ALL	0764	

BPL

Model No	Codes	Notes
ALL	0310 0065 0584	
ALL	1073	V6 or Higher RCU Required

BRANDT

Model No	Codes	Notes
ALL	0653	NOT A V4 RCU
ALL	0137 0363 0224 0226 0315 0499 0371 0588	

BRANDT ELECTRONIQUE

Model No	Codes	Notes
ALL	0315 0363	

BRINKMANN

Model No	Codes	Notes
3789TEXT	0696	V4 or Higher RCU Required
ALL	1696	
ALL	0065 0584 0547 0446 0514	
ALL	0696	V4 or Higher RCU Required

BRIONVEGA

Model No	Codes	Notes
ALL	0115 0065 0390 0584	

BRITANNIA

Model No	Codes	Notes
ALL	0244 0245	

BROTHER

Model No	Codes	Notes
ALL	0292	

BRUNS

Model No	Codes	Notes
ALL	0115	

BSR

Model No	Codes	Notes
ALL	0322 0191 0389	

BTC

Model No	Codes	Notes
ALL	0246	

BUSH

Model No	Codes	Notes
11AK20	0696	V4 or Higher RCU Required
1433	0696	V4 or Higher RCU Required
1434	0696	V4 or Higher RCU Required
1434AK20	0696	V4 or Higher RCU Required
1438	0696	V4 or Higher RCU Required
1454	0696	V4 or Higher RCU Required
1473T	0696	V4 or Higher RCU Required
1474T	0696	V4 or Higher RCU Required
1477T	0705	V4 or Higher RCU Required
1478T	0696	V4 or Higher RCU Required
1496MTV	0645	V4 or Higher RCU Required
14971	0642	V4 or Higher RCU Required
2030T	0065	
2031T	0065	
2034T	0065	
2037T	0065	
20382SIL	0742	V4 or Higher RCU Required
2054T	0288	
2059NTX	0065	
2137T (SIL)	0584	
2138T (SIL)	0742	V4 or Higher RCU Required
2163	0065	
2571	0065	
2571NTX	0065	
2850	0065	
2857	0065	
2863NTX	0065	
2867	0065	
2867NTX	0065	
2868NTX	0065	
2871NTX	0065	

2872NTX	0065	
2874	0065	
2874NTX	0065	
2876NPX	0246	
2878NTX	0742	V4 or Higher RCU Required
2878NTX (SIL)	0742	V4 or Higher RCU Required
2878NTXSIL	0742	V4 or Higher RCU Required
2890D	0688	V4 or Higher RCU Required
6690D	0688	V4 or Higher RCU Required
6VM187	0742	V4 or Higher RCU Required
7690D	0688	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	1584 1928 1932 1936	V6 or Higher RCU Required
ALL	0339 0035 0232 0288	
ALL	0714 0724	V4 or Higher RCU Required
ALL	0642 0645 0688 0696 0705 0726 0742	V4 or Higher RCU Required
ALL	0246 0263 0377 0037 0064 0065 0310 0300 0383 0391 0402 0547 0292 0239 0312 0609 0322 0339 0515 0236 0389 0191 0245 0584	
ALL	1065 0806 1696 1287 1271	
CI14B50/F	0742	V4 or Higher RCU Required
CTV3418	0696	V4 or Higher RCU Required
DVD140TV	0726	V4 or Higher RCU Required
DVD660TV	0584	
DVD760TV	0584	
IDTV	0688	V4 or Higher RCU Required
INTERNET TV	0642	V4 or Higher RCU Required
ITV2101	0642	V4 or Higher RCU Required
ITV2112	0642	V4 or Higher RCU Required
ITV2800	0642	V4 or Higher RCU Required
ITV6600	0642	V4 or Higher RCU Required
ITV8401	0642	V4 or Higher RCU Required
ITV8402	0642	V4 or Higher RCU Required
KWR2020	0642	V4 or Higher RCU Required
NR2878NTX (SIL)	0742	V4 or Higher RCU Required

NR2878NTXSIL	0742	V4 or Higher RCU Required
NRITV2112	0642	V4 or Higher RCU Required
NRITV6600	0642	V4 or Higher RCU Required
NRWS6680SIL	0742	V4 or Higher RCU Required
R03	0696	V4 or Higher RCU Required
RF2185NTXSIL	0742	V4 or Higher RCU Required
RF6682VPL	0742	V4 or Higher RCU Required
RF6685VPL (SIL)	0742	V4 or Higher RCU Required
RF7682VPL	0742	V4 or Higher RCU Required
RF7685VPLS	0742	V4 or Higher RCU Required
WR2020	0642	V4 or Higher RCU Required
WS5673	0584	
WS5680SIL	0742	V4 or Higher RCU Required
WS6671	0065	
WS6672	0584	
WS6673	0584	
WS6673SIL	0584	
WS6674	0584	
WS6675	0584	
WS6675 (SIL)	0584	
WS6678	0065	
WS6680	0742	V4 or Higher RCU Required
WS6680 (SIL)	0742	V4 or Higher RCU Required
WS6690D	0688	V4 or Higher RCU Required
WS7671	0584	
WS7680SIL	0742	V4 or Higher RCU Required
WS7680SILXI	0742	V4 or Higher RCU Required

CAIHONG

Model No	Codes	Notes
ALL	0037	

CANTON

Model No	Codes	Notes
----------	-------	-------

ALL	0246	
-----	------	--

CAPSONIC

Model No	Codes	Notes
----------	-------	-------

ALL	0292	
-----	------	--

CARAD

Model No	Codes	Notes
----------	-------	-------

ALL	1065 1696	
-----	-----------	--

ALL	0065 0584	
-----	-----------	--

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

CARENA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

ALL	0483	
-----	------	--

CARREFOUR

Model No	Codes	Notes
----------	-------	-------

ALL	0064 0098 0065 0584	
-----	---------------------	--

CARVER

Model No	Codes	Notes
----------	-------	-------

ALL	0198	
-----	------	--

CASCADE

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0037 0584	
-----	----------------	--

CASIO

Model No	Codes	Notes
ALL	0065 0584 0191 0377	
ALL	1932	V6 or Higher RCU Required

CATHAY

Model No	Codes	Notes
ALL	0065 0584 0502	

CCE

Model No	Codes	Notes
ALL	0065 0245 0584	

CELLO

Model No	Codes	Notes
ALL	0065	
HTW28	0065	

CENTRUM

Model No	Codes	Notes
ALL	1065	

CENTURION

Model No	Codes	Notes
ALL	0065 0584	

CENTURY

Model No	Codes	Notes
ALL	0241	
ALL	0115 0275 0266	

CGE

Model No	Codes	Notes
ALL	1932	V6 or Higher RCU Required
ALL	0102 0275 0104 0446 0398 0191 0304	

CHANGCHENG

Model No	Codes	Notes
ALL	0037 0292 0402 0440	
ALL	0689	V6 or Higher RCU Required

CHANGFEI

Model No	Codes	Notes
ALL	0037 0402	

CHANGFENG

Model No	Codes	Notes
ALL	0292 0440	
ALL	0724	V4 or Higher RCU Required

CHANGHAI

Model No	Codes	Notes
ALL	0037	

CHANGHONG

Model No	Codes	Notes
ALL	0037 0292 0536	

CHENGDU

Model No	Codes	Notes
----------	-------	-------

ALL 0037

CHESTRON

Model No	Codes	Notes
----------	-------	-------

ALL NO CODES AVAILABLE

CHING TAI

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0207 0502

CHUN YUN

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0207 0502

CHUNFENG

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292

CHUNG HSIN

Model No	Codes	Notes
----------	-------	-------

ALL 0502 0136 0064

CHUNGFENG

Model No	Codes	Notes
----------	-------	-------

ALL 0440

CHUNSUN

Model No	Codes	Notes
----------	-------	-------

ALL 0037

CIMLINE

Model No	Codes	Notes
ALL	0241 0115 0275	
ALL	0037 0263 0246	

CINEX

Model No	Codes	Notes
ALL	1584	V6 or Higher RCU Required

CITY

Model No	Codes	Notes
ALL	0037	

CLARIVOX

Model No	Codes	Notes
ALL	0348 0130	
ALL	0446 0098 0065 0584	
ALL	1191	

CLATRONIC

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	0245 0399 0246 0275 0065 0037 0292 0104 0398 0607 0584 0634	
ALL	1932	V6 or Higher RCU Required
CTV502STNT	0742	V4 or Higher RCU Required
CTV502STVT	0742	V4 or Higher RCU Required

CLAYTON

Model No	Codes	Notes
ALL	10685	

CMS

Model No	Codes	Notes
ALL	0244	

CMS HIGHTEC

Model No	Codes	Notes
ALL	0245	

COMBITECH

Model No	Codes	Notes
ALL	1936	V6 or Higher RCU Required

CONCORDE

Model No	Codes	Notes
ALL	0037	

CONDOR

Model No	Codes	Notes
ALL	0065 0398 0584 0244 0037 0310 0275 0446 0191 0292 0498	

CONIC

Model No	Codes	Notes
ALL	0060	

CONRAD

Model No	Codes	Notes
ALL	0065 0584	

CONROWA

Model No	Codes	Notes
ALL	0724 0726	V4 or Higher RCU Required
ALL	0037 0292 0440	

CONTEC

Model No	Codes	Notes
ALL	0244 0037 0039 0064 0185 0292 0065 0584	

CONTINENTAL EDISON

Model No	Codes	Notes
ALL	0137 0224 0226 0315 0515	
ALL	0361 0427 0596	

COSMEL

Model No	Codes	Notes
ALL	0037 0365 0065 0584	

CREZAR

Model No	Codes	Notes
ALL	0241	

CROSLEY

Model No	Codes	Notes
ALL	0112 0280 0241	
ALL	0191 0102 0104 0115 0275	

CROWN

Model No	Codes	Notes
ALL	0037 0514 0065 0387 0607 0446 0398 0104 0515 0236 0584 0634 0367	
ALL	1962	V6 or Higher RCU Required

ALL	0449 0397	
ALL	1065	
ALL	0742 0743	V4 or Higher RCU Required
CTF2805	0515	
CTV8130	0742	V4 or Higher RCU Required
CTV8230	0742	V4 or Higher RCU Required
CTV8330	0742	V4 or Higher RCU Required
CTV8380	0742	V4 or Higher RCU Required
CTV8501	0743	V4 or Higher RCU Required
CTV8511	0743	V4 or Higher RCU Required
CTV8535	0742	V4 or Higher RCU Required
CTV8711	0742	V4 or Higher RCU Required
CTV8735	0742	V4 or Higher RCU Required
CTV8954S	0742	V4 or Higher RCU Required
CTV9230	0742	V4 or Higher RCU Required
CTV9315	0743	V4 or Higher RCU Required
GRP21NT	0065	

CRYSTAL

Model No	Codes	Notes
----------	-------	-------

ALL	0459	
-----	------	--

CS ELECTRONICS

Model No	Codes	Notes
----------	-------	-------

ALL	0244 0275 0246	
-----	----------------	--

CTC

Model No	Codes	Notes
----------	-------	-------

ALL	0275	
-----	------	--

CTX

Model No	Codes	Notes
----------	-------	-------

ALL	1784	
-----	------	--

CURTIS MATHES

Model No	Codes	Notes
----------	-------	-------

ALL	0194	
-----	------	--

CYBERHOME

Model No	Codes	Notes
----------	-------	-------

ALL	1204	
-----	------	--

CYBERTON

Model No	Codes	Notes
----------	-------	-------

ALL	0246	
-----	------	--

CYTRONIX

Model No	Codes	Notes
----------	-------	-------

ALL	1326	
-----	------	--

DAEWOO

Model No	Codes	Notes
----------	-------	-------

14C4T	0662	V4 or Higher RCU Required
-------	------	---------------------------

28A7	0662	V4 or Higher RCU Required
------	------	---------------------------

52IF112	0652	V4 ONLY RCU
---------	------	-------------

ALL	0689 1937 1930 1936	V6 or Higher RCU Required
-----	---------------------	---------------------------

ALL	0502 0198 0136 0536 0652	
-----	--------------------------	--

ALL	0652	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0037 0065 0402 0244 0527 0245 0246 0584	
-----	---	--

ALL	0662	V4 or Higher RCU Required
-----	------	---------------------------

ALL	1300 1231 1294 1165 0869 0908 1246 0904	
-----	---	--

AV28B5EES	0652	V4 ONLY RCU
-----------	------	-------------

DDT21H9S	0662	V4 or Higher RCU Required
----------	------	---------------------------

DMQ2593	0065	
---------	------	--

DMQ2997	0065	
DSC3210E	0652	V4 ONLY RCU
DSC3210EGB	0652	V4 ONLY RCU
DSC3220EGC	0652	V4 ONLY RCU
DSC3270E	0652	V4 ONLY RCU
DSC3270EGB	0652	V4 ONLY RCU
DT20C4T	0662	V4 or Higher RCU Required
DTA21Y1P	0652	V4 ONLY RCU
DTE25G7GB	0662	V4 or Higher RCU Required
DTE28	0662	V4 or Higher RCU Required
DTE28617	0662	V4 or Higher RCU Required
DTE2887GBS	0662	V4 or Higher RCU Required
DTE2898GB	0662	V4 or Higher RCU Required
DTE289GB	0662	V4 or Higher RCU Required
DTE28A74GB	0662	V4 or Higher RCU Required
DTE28A75	0662	V4 or Higher RCU Required
DTE28A76BS	0662	V4 or Higher RCU Required
DTE28A7GB	0662	V4 or Higher RCU Required
DTE28A7GBS	0662	V4 or Higher RCU Required
DTE28G75	0662	V4 or Higher RCU Required
DTE28G7F	0662	V4 or Higher RCU Required
DTE28G7GB	0662	V4 or Higher RCU Required
DTE28G8	0662	V4 or Higher RCU Required
DTE29G3GB	0662	V4 or Higher RCU Required
DTF29	0662	V4 or Higher RCU Required
DTL25G7GB	0662	V4 or Higher RCU Required
DTP25	0662	V4 or Higher RCU Required
DTP28	0662	V4 or Higher RCU Required
DTP28A7GBS	0662	V4 or Higher RCU Required
DTW28W2GB100	0662	V4 or Higher RCU Required
DTY28W5GB	0662	V4 or Higher RCU Required
DVN14F6N	0652	V4 ONLY RCU
DVN14F7N	0652	V4 ONLY RCU
DVN20F6N	0652	V4 ONLY RCU

DVN20F7N	0652	V4 ONLY RCU
DVT1482P	0662	V4 or Higher RCU Required
DVT20F6LA	0652	V4 ONLY RCU
DVX28W5S	0662	V4 or Higher RCU Required
DWF28	0662	V4 or Higher RCU Required
DWF28W	0662	V4 or Higher RCU Required
DWF28W8GB	0662	V4 or Higher RCU Required
DWP28W2GB	0662	V4 or Higher RCU Required
DWX28	0662	V4 or Higher RCU Required
DWX2880GB	0662	V4 or Higher RCU Required
DWX2888GB	0536	
DWX28W	0662	V4 or Higher RCU Required
DWX28W5GB	0662	V4 or Higher RCU Required
F20C4N	0662	V4 or Higher RCU Required
GB1458T1	0652	V4 ONLY RCU
GB147T1	0652	V4 ONLY RCU
GB14C4N	0662	V4 or Higher RCU Required
GB14C4NT	0662	V4 or Higher RCU Required
GB14F7T1	0652	V4 ONLY RCU
GB14F8S	0652	V4 ONLY RCU
GB14F8T1	0652	V4 ONLY RCU
GB14F8T2	0652	V4 ONLY RCU
GB14H1N	0244	
GB14H2NBL	0652	V4 ONLY RCU
GB20F7T2	0652	V4 ONLY RCU
GB20F8T2	0652	V4 ONLY RCU
GB20T8ST	0652	V4 ONLY RCU
GB21AST	0065	
GB21F1T2	0652	V4 ONLY RCU
GB21F1T2S	0652	V4 ONLY RCU
GB21T5ST	0652	V4 ONLY RCU
GB2898ST	0652	V4 ONLY RCU
GB28G2ST	0652	V4 ONLY RCU
GB28G2STS	0652	V4 ONLY RCU

IR2898ST	0652	V4 ONLY RCU
QA12P	0065	
R35A01	0652	V4 ONLY RCU
R35F18	0652	V4 ONLY RCU
R35F22	0652	V4 ONLY RCU
R35F27	0652	V4 ONLY RCU
R40A01	0662	V4 or Higher RCU Required
R46G22	0662	V4 or Higher RCU Required
S20C4L	0662	V4 or Higher RCU Required
S20C4NTL	0662	V4 or Higher RCU Required
T202	0065	
T2023QA12B	0065	
TVC142T	0652	V4 ONLY RCU

DAINICHI

Model No	Codes	Notes
ALL	0246 0244	

DANSAI

Model No	Codes	Notes
ALL	0064	
ALL	0292 0065 0063 0244 0060 0584 0037 0245 0236	

DANSETTE

Model No	Codes	Notes
ALL	0440	

DANTAX

Model No	Codes	Notes
ALL	0398 0514 0634	
ALL	0742 0743	V4 or Higher RCU Required
ALL	1936	V6 or Higher RCU Required

DLBO	0742	V4 or Higher RCU Required
MND41	0743	V4 or Higher RCU Required

DATSURA

Model No	Codes	Notes
ALL	0236	

DAVIS

Model No	Codes	Notes
ALL	0764	

DAWA

Model No	Codes	Notes
ALL	0065 0037 0584	

DAYTEK

Model No	Codes	Notes
ALL	1235	
ALL	0726	V4 or Higher RCU Required

DAYTON

Model No	Codes	Notes
ALL	1235	
ALL	0037	

DAYTRON

Model No	Codes	Notes
ALL	0402 0037 0065 0584	

DAYU

Model No	Codes	Notes
ALL	0689	V6 or Higher RCU Required
ALL	0402	

DECCA

Model No	Codes	Notes
ALL	0065 0100 0544 0300 0277 0245 0272 0077 0103 0584	
ALL	0649	V4 or Higher RCU Required
ALL	1084 1932 1936	V6 or Higher RCU Required
ALL	0061	
ALL	1165	
D14RKG6LS	0649	V4 or Higher RCU Required
D14TFGS	0065	
D21TKG5S	0649	V4 or Higher RCU Required
D25TEF6	0065	
DN8159	0065	

DEGRAAF

Model No	Codes	Notes
ALL	0236 0255 0072 0576 0191 0391	
BT3314020	0236	

DEGRAAF

Model No	Codes	Notes
CD51JS2	0236	

DEITRON

Model No	Codes	Notes
ALL	0065 0584 0402 0246	

DELL

Model No	Codes	Notes
ALL	1292	
ALL	0065	
W1700	0065	
W1900	0065	

DENKO

Model No	Codes	Notes
ALL	0292	

DENVER

Model No	Codes	Notes
ALL	1217 2016	
ALL	0065 0584 0634 0615	

DER

Model No	Codes	Notes
ALL	0221 0218	

DERWENT

Model No	Codes	Notes
ALL	0229	

DESMET

Model No	Codes	Notes
ALL	0348	
ALL	0065 0584 0037 0115 0379	

DIAMANT

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

DIAMOND

Model No	Codes	Notes
ALL	0292 0244 0399 0037	
ALL	0724 0726	V4 or Higher RCU Required
ALL	0034	
DTV3401	0726	V4 or Higher RCU Required
DTV8401	0726	V4 or Higher RCU Required

DIBOSS

Model No	Codes	Notes
ALL	0065	
LT17DLF	0065	

DIGATRON

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
ALL	0065 0584	

DIGI X

Model No	Codes	Notes
ALL	0908	

DIGIHOME

Model No	Codes	Notes
ALL	1177	

DIGILINE

Model No	Codes	Notes
ALL	0065 0584 0133	

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

ALL	1696	
-----	------	--

DIGILOGIC

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

DIGITOR

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

ALL	0916 1752	
-----	-----------	--

DIGIVISION

Model No	Codes	Notes
----------	-------	-------

ALL	0389	
-----	------	--

DIK

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

DIXI

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0065 0584 0275 0245 0115	
-----	-------------------------------	--

DL

Model No	Codes	Notes
----------	-------	-------

ALL	0900 0893	
-----	-----------	--

ALL	0065 0615	
-----	-----------	--

DMTECH

Model No	Codes	Notes
ALL	1992	
DOMEOS		

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
TV5500DL	0696	V4 or Higher RCU Required

DOMLAND

Model No	Codes	Notes
ALL	0422	

DONGBA

Model No	Codes	Notes
ALL	0037	

DONGHAI

Model No	Codes	Notes
ALL	0037	

DORIC

Model No	Codes	Notes
ALL	0229 0377	

DREAM VISION

Model No	Codes	Notes
ALL	0701 1732	

DSE

Model No	Codes	Notes
----------	-------	-------

ALL	0916	
ALL	1584	V6 or Higher RCU Required

DTS

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

DUAL

Model No	Codes	Notes
----------	-------	-------

ALL	0547 0371 0065 0245 0377 0572 0584 0191 0559 0659	
-----	--	--

ALL	1932	V6 or Higher RCU Required
-----	------	---------------------------

ALL	1165 1265	
-----	-----------	--

ALL	0331 0287 0427 0380 0422 0364	
-----	-------------------------------	--

DUALTEC

Model No	Codes	Notes
----------	-------	-------

ALL	0245 0191 0287	
-----	----------------	--

DUMONT

Model No	Codes	Notes
----------	-------	-------

ALL	1932	V6 or Higher RCU Required
-----	------	---------------------------

ALL	0098 0115 0245 0100 0132 0045	
-----	-------------------------------	--

ALL	0241 0130	
-----	-----------	--

DUNAI

Model No	Codes	Notes
----------	-------	-------

ALL	0572 0191	
-----	-----------	--

DURABRAND

Model No	Codes	Notes
----------	-------	-------

2127N	0743	V4 or Higher RCU Required
28T67WM	0742	V4 or Higher RCU Required
ALL	1465	
ALL	0742 0743	V4 or Higher RCU Required
ALL	0065 0584	
PTV8017	0065	

DUX

Model No	Codes	Notes
ALL	0040 0065 0584	

D-VISION

Model No	Codes	Notes
ALL	0065 0584	

DYNATRON

Model No	Codes	Notes
ALL	0065 0584 0040	

EASY LIVING

Model No	Codes	Notes
ALL	1276 1287	

ECE

Model No	Codes	Notes
ALL	0065 0584	

EDDISON

Model No	Codes	Notes
ALL	0137 0224 0226 0427 0361 0515 0596	

EDDISON-MINERVA

Model No	Codes	Notes
ALL	0515	

E-ELITE

Model No	Codes	Notes
ALL	0246	

EIKI

Model No	Codes	Notes
ALL	0763	

ELBE

Model No	Codes	Notes
ALL	0266 0390 0398 0191 0065 0584 0246 0219 0312 0245 0544 0389	

ELBE-SHARP

Model No	Codes	Notes
ALL	0544	

ELCIT

Model No	Codes	Notes
ALL	0115 0275 0544 0103 0191	

ELEKTA

Model No	Codes	Notes
ALL	0037 0065 0584 0292 0310	

ELEKTRA

Model No	Codes	Notes
----------	-------	-------

ALL	0045	
-----	------	--

ELEKTRONSKA

Model No	Codes	Notes
----------	-------	-------

ALL	0335	
-----	------	--

ELFUNK

Model No	Codes	Notes
----------	-------	-------

ALL	1236 1065	V6 or Higher RCU Required
-----	-----------	---------------------------

ELG

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

ELIN

Model No	Codes	Notes
----------	-------	-------

ALL	0476	
-----	------	--

ALL	0132 0377 0065 0133 0244 0389 0576 0037 0191 0584	
-----	--	--

ELITE

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0246 0584	
-----	----------------	--

ELLIE

Model No	Codes	Notes
----------	-------	-------

ALL	0816 0817	
-----	-----------	--

ELTA

Model No	Codes	Notes
ALL	0292 0037 0244 0459 0502	
EMCO		
Model No	Codes	Notes
ALL	0275	
EMERSON		
Model No	Codes	Notes
ALL	0206 1696	
ALL	0652 0199	
ALL	1932 1937	V6 or Higher RCU Required
ALL	0742 0696	V4 or Higher RCU Required
ALL	0205 0115 0207 0275 0065 0584 0399 0098 0310 0389 0514 0398 0191 0104 0349	
EVT14F7	0652	V4 ONLY RCU
EVT20F7	0652	V4 ONLY RCU
EMPEROR		
Model No	Codes	Notes
ALL	0310	
ENZER		
Model No	Codes	Notes
ALL	0724	V4 or Higher RCU Required
EPSON		
Model No	Codes	Notes
ALL	0861 0868 0859 0909 1350 1150	
ERRES		

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0040 0584	
-----	----------------	--

ESC

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0245 0502	
-----	---------------------	--

ESTELE

Model No	Codes	Notes
----------	-------	-------

ALL	0191	
-----	------	--

ETHER

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

ETRON

Model No	Codes	Notes
----------	-------	-------

ALL	0311 0065 0191 0037 0584	
-----	--------------------------	--

EUROFEEL

Model No	Codes	Notes
----------	-------	-------

ALL	0292 0245	
-----	-----------	--

EUROLINE

Model No	Codes	Notes
----------	-------	-------

ALL	0065	
-----	------	--

EUROMAN

Model No	Codes	Notes
----------	-------	-------

ALL	0244 0292 0065 0584 0245 0398	
-----	-------------------------------	--

EUROPA

Model No	Codes	Notes
ALL	0065 0584	

EUROPHON

Model No	Codes	Notes
ALL	0065 0544 0103 0191 0245 0584 0275 0459 0244	

EVESHAM

Model No	Codes	Notes
ALL	1276	

EXCEL

Model No	Codes	Notes
ALL	0065 0584	

EXPERT

Model No	Codes	Notes
ALL	0191	

EXQUISIT

Model No	Codes	Notes
ALL	0065 0584 0275	

FAGOR

Model No	Codes	Notes
ALL	0065 0584	

FAIR TEC

Model No	Codes	Notes
----------	-------	-------

ALL	1219	
-----	------	--

FAMILY LIFE

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

FEILANG

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

FEILU

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

FEIYAN

Model No	Codes	Notes
----------	-------	-------

ALL	0292 0440	
-----	-----------	--

FEIYUE

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

FENNER

Model No	Codes	Notes
----------	-------	-------

ALL	0402 0037	
-----	-----------	--

FERGUSON

Model No	Codes	Notes
----------	-------	-------

405TX91	0101	
---------	------	--

51P7	0101	
59D3	0702	V4 or Higher RCU Required
70WF8000	0065	
A51F	0101	
ALL	0101 0363 0221 0218 0653 0137 0266 0371 0220 0315 0588 0065 0584 0063 0132 0136 0389 0499 0576 0471	
ALL	0033 0035 0236	
ALL	1932	V6 or Higher RCU Required
ALL	1065	
ALL	0702	V4 or Higher RCU Required
B39N	0266	
B59F	0363	
BDS29S	0065	
C51F	0363	
CE24WN4B	0236	
D59N	0363	
DS1NO	0363	
DSF68NX	0363	
FL32WX2	0653	NOT A V4 RCU
FL32WX2	0653	NOT A V4 RCU
FTV24FW1	0065	
FTV28FW1	0065	
FTV28WN1	0065	
FTV32100FW	0065	
FTV32FW1	0065	
FTV32WN1	0065	
M5517U1	0653	NOT A V4 RCU
M55200	0363	
M6322U	0653	
M7022U	0653	NOT A V4 RCU
M8421U	0653	NOT A V4 RCU
T10	0363	
T51N	0363	
T59N	0702	V4 or Higher RCU Required

TS1A2	0363	
TS9F	0363	
TX3790	0363	
TX685L2	0363	
TX807C	0653	NOT A V4 RCU
W7022U	0653	NOT A V4 RCU
W7023U	0588	

FIDELITY

Model No	Codes	Notes
ALL	0400 0544	
ALL	0244 0221 0460 0391 0379 0411 0065 0191 0399 0616 0292 0502 0540 0199 0389 0572 0584 0440 0559	
ALL	1932 1935 1936	V6 or Higher RCU Required
CTV3014F	0065	
CTV3221NF	0065	
CTV3228NF	0065	
CTV920	0292	

FILSAI

Model No	Codes	Notes
ALL	0245	

FINLANDIA

Model No	Codes	Notes
2242	0387	
40172726	0374	
ALL	0374 0387 0236 0391 0576 0389 0191 0100 0315 0371 0073	
CD14LZ2B	0387	

FINLUX

Model No	Codes	Notes
302B	0133	
50285	0374	
50F21	0133	
ALL	0132 0133 0065 0374 0245 0100 0544 0098 0115 0207 0104 0103 0584 0191 0508 0501	
ALL	0634 0649 0657 0659 0742 0743	V4 or Higher RCU Required
ALL	0130 0466	
ALL	1584	V6 or Higher RCU Required
ALL	0446	
ALL	0652	V4 or Higher RCU Required
CB142	0652	V4 ONLY RCU
CB212	0652	V4 ONLY RCU
COLOR55FOST	0742	V4 or Higher RCU Required
CTW2827T	0584	
FL51BK50	0743	V4 or Higher RCU Required
FL51BK502	0742	V4 or Higher RCU Required
FL55BKS	0742	V4 or Higher RCU Required
FL71FOST	0742	V4 or Higher RCU Required
FLB4BK50	0742	V4 or Higher RCU Required
FX702	0657	V4 or Higher RCU Required
GW82X8	0659	V4 or Higher RCU Required

FIRSTAR

Model No	Codes	Notes
ALL	0037	

FIRSTLINE

Model No	Codes	Notes
1030	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	0696 0742	V4 or Higher RCU Required

ALL	0037 0065 0244 0584 0245 0402 0275 0349 0191 0322 0572 0377 0559 0266 0100 0263 0236 0389	
ALL	1937	V6 or Higher RCU Required
ALL	0652	V4 or Higher RCU Required
ALL	1065 1696 1219 0836 1191	
FL14TXT	0696	V4 or Higher RCU Required
FL3798TX	0696	V4 or Higher RCU Required
FL3897	0696	V4 or Higher RCU Required
FLAV3799TX	0696	V4 or Higher RCU Required
FTX14	0696	V4 or Higher RCU Required
FX3798TX	0696	V4 or Higher RCU Required
FX6301	0742	V4 or Higher RCU Required
M3798TXT	0696	V4 or Higher RCU Required
R35F20	0652	V4 ONLY RCU
RFL70ES	0742	V4 or Higher RCU Required

FISHER

Model No	Codes	Notes
ALL	0132 0236 0185 0245 0115 0377 0100 0191 0398 0064 0389 0572 0073 0583	
ALL	0182 0331	
CFB2110STX	0185	

FLATDISPLAYS

Model No	Codes	Notes
ALL	0902	

FLINT

Model No	Codes	Notes
ALL	0065 0584 0100 0246 0292	

FNR

Model No	Codes	Notes
----------	-------	-------

ALL	0130	
-----	------	--

FORCE

Model No	Codes	Notes
----------	-------	-------

ALL	1177	
-----	------	--

FORGESTONE

Model No	Codes	Notes
----------	-------	-------

ALL	0221	
-----	------	--

FORMENTI

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0191 0584 0514 0244 0115 0104	
-----	------------------------------------	--

FORMENTI-PHOENIX

Model No	Codes	Notes
----------	-------	-------

ALL	0244	
-----	------	--

FORTRESS

Model No	Codes	Notes
----------	-------	-------

ALL	0121	
-----	------	--

ALL	0115	
-----	------	--

FRABA

Model No	Codes	Notes
----------	-------	-------

ALL	0398 0065 0584 0559	
-----	---------------------	--

FRIAC

Model No	Codes	Notes
----------	-------	-------

70003	0683	V4 or Higher RCU Required
-------	------	---------------------------

ALL	0130	
ALL	0037 0065 0584 0398 0527	
ALL	0683	V4 or Higher RCU Required

FRONTECH

Model No	Codes	Notes
----------	-------	-------

ALL	0476	
ALL	0502 0245 0275 0377 0459 0292 0037 0391 0191	

FUJICOM

Model No	Codes	Notes
----------	-------	-------

ALL	1301	
-----	------	--

FUJIMARO

Model No	Codes	Notes
----------	-------	-------

ALL	0893	
-----	------	--

FUJITSU

Model No	Codes	Notes
----------	-------	-------

ALL	0130 0234 0123	
ALL	0711	V4 or Higher RCU Required
ALL	0671	V4 or Higher RCU Required
ALL	0881	V6 or Higher RCU Required
ALL	0100 0207 0191 0245 0037 0065 0584 0389	
P42RM01B	0671	V4 ONLY RCU
P42RM07H	0711	V4 or Higher RCU Required
P42RT101B	0671	V4 ONLY RCU
PDS4214	0711	V4 or Higher RCU Required
PDS4234WS	0711	V4 or Higher RCU Required
PDS4242W	0711	V4 or Higher RCU Required
PDS42TR	0671	V4 ONLY RCU
PSP4201	0711	V4 or Higher RCU Required

FUJITSU GENERAL

Model No	Codes	Notes
ALL	0037 0245 0191	

FUJITSU SIEMENS

Model No	Codes	Notes
ALL	1326 1287	

FUNAI

Model No	Codes	Notes
14A111	0696	V4 or Higher RCU Required
ALL	1696	
ALL	0696	V4 or Higher RCU Required
ALL	0292 0322 0207 0440	
ALL	0199	

FURI

Model No	Codes	Notes
ALL	0292 0440	

FUTRONIC

Model No	Codes	Notes
ALL	0292	

FUTURE

Model No	Codes	Notes
ALL	0065 0584	

GALAXI

Model No	Codes	Notes
----------	-------	-------

ALL	0130	
ALL	0065 0584 0389 0191	

GALAXIS

Model No	Codes	Notes
ALL	0130	
ALL	0398 0065 0446 0584	

GALERIA

Model No	Codes	Notes
ALL	0037	

GBC

Model No	Codes	Notes
ALL	0037 0191 0402 0246 0391	
ALL	0549 0233	
ALL	0241	

GE

Model No	Codes	Notes
ALL	0763 0206	
ALL	0315 0588 0363 0137 0310 0371 0653	

GEANT CASINO

Model No	Codes	Notes
ALL	0191	

GEC

Model No	Codes	Notes
ALL	0191 0245 0377 0071 0103 0065 0389 0100 0544 0584	

GELOSO

Model No	Codes	Notes
ALL	0275 0402 0037 0191 0391	
ALL	0241	

GENERAL

Model No	Codes	Notes
ALL	0137 0499 0315	

GENERAL ELECTRIC

Model No	Codes	Notes
ALL	0371 0315	

GENERAL TECHNIC

Model No	Codes	Notes
ALL	0037	

GENESIS

Model No	Codes	Notes
ALL	0037 0065 0584	

GENEXXA

Model No	Codes	Notes
ALL	0246 0065 0191 0440 0521 0584 0037	

GERICOM

Model No	Codes	Notes
ALL	0893 1326 1234 1245 0908	

GIANT

Model No	Codes	Notes
----------	-------	-------

ALL	0245	
-----	------	--

GIBRALTER

Model No	Codes	Notes
----------	-------	-------

ALL	0045	
-----	------	--

GINTAI

Model No	Codes	Notes
----------	-------	-------

ALL	0502 0382	
-----	-----------	--

GOLDFUNK

Model No	Codes	Notes
----------	-------	-------

3703T	0696	V4 or Higher RCU Required
-------	------	---------------------------

ALL	1696	
-----	------	--

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

GOLDHAND

Model No	Codes	Notes
----------	-------	-------

ALL	0244	
-----	------	--

GOLDLINE

Model No	Codes	Notes
----------	-------	-------

ALL	0365	
-----	------	--

GOLDSTAR

Model No	Codes	Notes
----------	-------	-------

ALL	0742 0743	V4 or Higher RCU Required
-----	-----------	---------------------------

ALL	1962	V6 or Higher RCU Required
-----	------	---------------------------

ALL	0065 0405 0318 0275 0037 0391 0137 0459 0389 0398 0191 0244 0502 0245 0584 0311 0634 0072	
-----	--	--

ALL	0246 0060	
ALL	0206	
CI21C22F	0065	
CIT9322	0244	
CL14F85B	0743	V4 or Higher RCU Required

GOODING

Model No	Codes	Notes
ALL	0515	

GOODMANS

Model No	Codes	Notes
00294382	0527	
1476TS	0662	V4 or Higher RCU Required
147TT	0399	
148T	0065	
148T57	0065	
201BT	0065	
2028T	0065	
2045TX	0065	
2050R	0065	
205N	0065	
2065TS	0662	V4 or Higher RCU Required
2066TS	0662	V4 or Higher RCU Required
206NS	0662	V4 or Higher RCU Required
20C1	0065	
20T3TUSU	0065	
2145TS	0662	V4 or Higher RCU Required
215N	0065	
2160PF	0742	V4 or Higher RCU Required
216NS	0662	V4 or Higher RCU Required
217NS	0662	V4 or Higher RCU Required
218NS	0662	V4 or Higher RCU Required

2195TX	0065	
21B1TW58S	0065	
255NS	0662	V4 or Higher RCU Required
255NS	0065	
255NSB	0662	V4 or Higher RCU Required
257NS	0662	V4 or Higher RCU Required
285DPL	0508	
285NS	0662	V4 or Higher RCU Required
285NSB	0527	
285NSB	0662	V4 or Higher RCU Required
289NS	0662	V4 or Higher RCU Required
28BKJ	0065	
295NS	0662	V4 or Higher RCU Required
2TW28D11	0662	V4 or Higher RCU Required
336NIS	0065	
336NS	0065	
930	0696	V4 or Higher RCU Required
ALL	0689 1936 1937	V6 or Higher RCU Required
ALL	0662 0696 0742	V4 or Higher RCU Required
ALL	0065 0064 0100 0588 0285 0037 0292 0544 0207 0318 0363 0399 0402 0515 0527 0392 0371 0245 0297 0584 0103 0263 0508 0063 0616 0246 0607 0615	
ALL	0563 0060 0055	
ALL	1928	V6 or Higher RCU Required
ALL	1287 1065 1928 1696 0908 1336	
ALL	0652	V4 or Higher RCU Required
DTE28A6F	0652	V4 or Higher RCU Required
DTE28A6FSU	0652	V4 ONLY RCU
DTE28A6PSV	0652	V4 ONLY RCU
DTE28A6SV	0652	V4 ONLY RCU
F32WTF	0065	
GB1458T1	0652	V4 ONLY RCU
GB2580	0363	
GB2880B	0363	

GD2880A	0363	
GD2880D	0363	
GTV14DVDX1,	0065	
GTV211	0065	
GTV288	0065	
GTV34R4	0696	V4 or Higher RCU Required
GTV34R6BLU4	0696	V4 or Higher RCU Required
GTV34T5AK20	0696	V4 or Higher RCU Required
GTV34T6	0696	V4 or Higher RCU Required
GTV42P4	0065	
GTV48T2	0065	
GTV66W1	0065	
GTV69RF2	0065	
GTV69W3S	0065	
GTV69W4	0065	
GTV86W3	0065	
GTV86W3SIL	0065	
GTV86W4	0065	
K2105	0584	
K24W10	0065	
K28W05	0065	
K28W10	0065	
LD2602	0065	
NR2160PF	0742	V4 or Higher RCU Required
R35F18	0652	V4 ONLY RCU
R35F30	0652	V4 ONLY RCU
R40A01	0662	V4 or Higher RCU Required
ST70700ANIC	0563	
TROC17UPSU	0065	
TVC141	0652	V4 ONLY RCU
TVC142T	0652	V4 ONLY RCU
TVC145T	0652	V4 ONLY RCU
TVC146TWS	0652	V4 ONLY RCU
TVC201T	0652	V4 ONLY RCU

TVC202TS	0662	V4 or Higher RCU Required
TW28D11	0662	V4 or Higher RCU Required
VT1456PSA	0402	
W280NF	0065	
W282NST	0065	
W288NF	0065	
W288NS	0065	
W321NSA	0065	
W322NS	0065	
W325NST	0065	
WTF32	0065	

GORENJE

Model No	Codes	Notes
ALL	0398	

GPM

Model No	Codes	Notes
ALL	0246	

GRADIENTE

Model No	Codes	Notes
ALL	0198 0065 0584	

GRAETZ

Model No	Codes	Notes
ALL	0191 0389 0399 0574 0065 0367 0584	
ALL	0742	V4 or Higher RCU Required
ALL	1191	

GRANADA

Model No	Codes	Notes
----------	-------	-------

ALL	0530
ALL	0072 0174 0536
ALL	0379 0387 0391 0544 0229 0065 0236 0245 0073 0367 0064 0530 0588 0501 0384 0040 0254 0103 0136 0104 0100 0363 0584 0191 0253 0497 0371 0576
C41HF4D	0236
C51E25	0391
L5103312	0236

GRANDIN

Model No	Codes	Notes
36MM001ARG	0696	V4 or Higher RCU Required
51BPS89	0743	V4 or Higher RCU Required
51BPS99	0743	V4 or Higher RCU Required
70SBI003ARG	0733	V4 or Higher RCU Required
8UMB1003ARG	0733	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	0696 0742 0743	V4 or Higher RCU Required
ALL	1065 1696 0893 1219 0908	
ALL	0733	V4 or Higher RCU Required
ALL	0065 0310 0584 0037 0191 0402 0246 0607	
GR1499	0696	V4 or Higher RCU Required

GRONIC

Model No	Codes	Notes
ALL	0245 0191	

GRUNDIG

Model No	Codes	Notes
32WF100	0584	
500IRD1	0563	
822DOOFA	0563	
ALL	0582 0233	

ALL	0563 0515 0471 0098 0584 0219 0104 0223 0065 0536 0615 0037 0064 0398
ALL	1963 1936
ALL	1302 1251 1336 0206
CVC2030ST	0563
FT70700	0563
GT1401	0515
GT210S	0563
MW70/500	0536
MW702700	0582
MW82	0563
MW822699	0563
MW82500IRDT	0563
MW82701	0582
P371010	0065
ST55730	0582
ST63725	0563
ST63755	0563
ST70700	0563
ST70875	0563
T551010	0471
T551020	0471
T551120	0471
T701021	0065
T701022	0065
TF553020	0563
W702020	0584
W702030	0065
W822030	0584
WF703020	0471

V6 or Higher RCU Required

GRUNKEL

Model No	Codes	Notes
ALL	1191	

GRUNPY

Model No	Codes	Notes
ALL	0207	

H&B

Model No	Codes	Notes
ALL	0836	

HAIER

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required
ALL	0292	
BT0018AJ	0726	V4 or Higher RCU Required
HT2119	0726	V4 or Higher RCU Required
HYF28D	0726	V4 or Higher RCU Required

HAIHONG

Model No	Codes	Notes
ALL	0037	

HAIYAN

Model No	Codes	Notes
ALL	0292 0440	

HALIFAX

Model No	Codes	Notes
ALL	0244 0292 0245	

HAMMERSTEIN

Model No	Codes	Notes
----------	-------	-------

ALL 0292

HAMPTON

Model No	Codes	Notes
----------	-------	-------

ALL 0245 0244

HANIMEX

Model No	Codes	Notes
----------	-------	-------

ALL 0322 0246

ALL 1936 V6 or Higher RCU Required

HANSEATIC

Model No	Codes	Notes
----------	-------	-------

ALL 0662 0742 V4 or Higher RCU Required

ALL 0836

ALL 0689 V6 or Higher RCU Required

ALL 0733 V4 or Higher RCU Required

ALL 0065 0584 0389 0527 0547 0377 0572 0191 0310
0398 0037 0322 0245 0459 0304 0115 0405 0379

CTV2083VT 0662 V4 or Higher RCU Required

CTV2195AVT 0662 V4 or Higher RCU Required

CTV406950 0733 V4 or Higher RCU Required

CTV801692S 0733 V4 or Higher RCU Required

CTV821692S 0733 V4 or Higher RCU Required

R40A01 0662 V4 or Higher RCU Required

HANTAREX

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0065 0544 0584 0266

ALL 0130 0355 0241

ALL 0857

HANTOR

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

HARLEY DAVIDSON

Model No	Codes	Notes
----------	-------	-------

ALL	0071 0207	
-----	-----------	--

HARSPER

Model No	Codes	Notes
----------	-------	-------

ALL	0893	
-----	------	--

HARWA

Model No	Codes	Notes
----------	-------	-------

ALL	1224 1297	
-----	-----------	--

HARWOOD

Model No	Codes	Notes
----------	-------	-------

ALL	0285 0037 0065 0440 0584 0515	
-----	-------------------------------	--

ALL	0060 0345	
-----	-----------	--

HAUPPAUGE

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

HCM

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0310 0440 0065 0584 0245 0246 0446 0292	
-----	---	--

HEDZON

Model No	Codes	Notes
ALL	0584 0065	
HEMA		

Model No	Codes	Notes
ALL	0245 0037	
HEMMERMANN		

Model No	Codes	Notes
ALL	0377 0572	
HIFIVOX		

Model No	Codes	Notes
ALL	0137 0224 0226	
HIGASHI		

Model No	Codes	Notes
ALL	0244	
HIGHLINE		

Model No	Codes	Notes
ALL	0292 0065 0584	
HIKONA		

Model No	Codes	Notes
ALL	0502 0246	
ALL	2011	
HINARI		

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0064 0065 0207 0246 0263 0515 0383 0392 0311 0191 0471 0236 0239 0584 0322 0292
-----	---

ALL	1936	V6 or Higher RCU Required
-----	------	---------------------------

HISAWA

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	0724	V4 or Higher RCU Required
ALL	1236	V6 or Higher RCU Required
ALL	0310 0246	
ALL	1936	V6 or Higher RCU Required

HISENSE

Model No	Codes	Notes
ALL	0037 0255 0536 0584	
ALL	0236	
ALL	1236	V6 or Higher RCU Required
ALL	0724	V4 or Higher RCU Required

HIT

Model No	Codes	Notes
ALL	0115	

HITACHI

Model No	Codes	Notes
105W	0253	
2156TN	0509	
21F45	0509	
22114TE	0253	
26LD6200	0065	
2879DB	0536	
28LD5200E	0509	

28W40	0747	V4 or Higher RCU Required
28W410	0509	
28W510	0509	
28W511	0509	
28W511TN	0253	
28WF523	0747	V4 or Higher RCU Required
29F45	0509	
32PD3000	0747	V4 or Higher RCU Required
32PD3000	0509	
32PD5200	0509	
32PD5300	0747	V4 or Higher RCU Required
32W35	0747	V4 or Higher RCU Required
32W40	0747	V4 or Higher RCU Required
32W510	0509	
32W511	0509	
32WF523	0747	V4 or Higher RCU Required
32WF720	0747	V4 or Higher RCU Required
32WF727	0747	V4 or Higher RCU Required
32WF810	0747	V4 or Higher RCU Required
3DS	0253	
42PD5000	0509	
42PD5000	0747	V4 or Higher RCU Required
42PD5200	0747	V4 or Higher RCU Required
42PD5300	0747	V4 or Higher RCU Required
42PD7200	0747	V4 or Higher RCU Required
42PMA400E	0509	
43WP910	0747	V4 or Higher RCU Required
55WP910	0747	V4 or Higher RCU Required
ALL	0662 0747 0772	V4 or Higher RCU Required
	0253 0384 0377 0606 0469 0591 0509 0065 0071 0072 0064 0133 0224 0245 0255 0191 0391 0576 0544 0501 0222 0100 0371 0226 0304 0103 0497 0527 0584 0334 0123 0137 0178 0549 0136 0389 0540 0508 0657	
ALL	1253 0604 0758 0206 1165 0805 0825 0765 1065 0912 1604 1177 1222 1183 1185	

ALL	0334 0037 0173 0060 0178 0549 0334 0185 0207 0544 0502 0536 0387	
ALL	0606	V4 or Higher RCU Required
ALL	1509 1073	V6 or Higher RCU Required
BS415	0173	
C2114R	0253	
C2114T	0253	
C2114T311	0253	
C2114TE	0173	
C2118T	0509	
C2119R	0509	
C2121T	0747	V4 or Higher RCU Required
C2125T	0772	V4 or Higher RCU Required
C2126S	0772	V4 or Higher RCU Required
C2133TN	0384	
C213TN	0384	
C2142	0772	V4 or Higher RCU Required
C2142N	0772	V4 or Higher RCU Required
C2143S	0772	V4 or Higher RCU Required
C2144S	0065	
C2146TN	0253	
C2156TN	0253	
C2156TN	0606	
C21F60S	0065	
C24W1TN	0253	
C24W1TN	0509	
C24W410	0253	
C24W410SN	0253	
C24W430N	0747	V4 or Higher RCU Required
C2509T	0173	
C2514T	0253	
C2514TE	0253	
C2514TE311	0253	
C2514TE311	0377	
C2519TG	0377	

C2524T	0591	
C2556TN	0509	
C2558TN	0384	
C2574TN	0253	
C2586TN	0253	
C2842	0772	V4 or Higher RCU Required
C2842N	0772	V4 or Higher RCU Required
C2844S	0065	
C2846TN	0253	
C2846TN311	0509	
C2848TN	0509	
C2856TN	0509	
C2886	0253	
C2886CN	0253	
C2886TN	0253	
C28W1TN	0509	
C28W35TN	0747	V4 or Higher RCU Required
C28W40TN	0747	V4 or Higher RCU Required
C28W410	0606	
C28W410	0509	
C28W410SN811	0606	
C28W411TN	0509	
C28W430N	0747	V4 or Higher RCU Required
C28W440	0772	V4 or Higher RCU Required
C28W440N	0772	V4 or Higher RCU Required
C28W460	0772	V4 or Higher RCU Required
C28W460N	0772	V4 or Higher RCU Required
C28W510	0509	
C28W510SN	0253	
C28W510TN	0509	
C28W511	0509	
C28W511N	0509	
C28W5211TN	0509	
C28WD2TN	0253	

C28WD2TN2	0253	
C28WF523N	0747	V4 or Higher RCU Required
C28WF540	0772	V4 or Higher RCU Required
C28WF560N	0772	V4 or Higher RCU Required
C2976TN	0509	
C32W1TN	0509	
C32W35TN	0747	V4 or Higher RCU Required
C32W40TN	0747	V4 or Higher RCU Required
C32W460N	0772	V4 or Higher RCU Required
C32W460SN	0065	
C32W511	0253	
C32WD2TN	0509	
C32WD2TN2	0253	
C32WF540	0772	V4 or Higher RCU Required
C32WF560N	0772	V4 or Higher RCU Required
CCE876E	0469	
CL21255	0772	V4 or Higher RCU Required
CL2854AN	0662	V4 or Higher RCU Required
CL28W30TAN	0747	V4 or Higher RCU Required
CLE902A	0253	
CLE921A	0253	
CLE932A	0747	V4 or Higher RCU Required
CLE933A	0747	V4 or Higher RCU Required
CLE941	0747	V4 or Higher RCU Required
CP2125T	0772	V4 or Higher RCU Required
CP2142	0772	V4 or Higher RCU Required
CPT2188	0377	
CPT2488	0377	
CT117TCT	0173	
CT172	0253	
CT2146TN	0509	
CT2576TN	0509	
CT2846TN	0253	
CT4W1TN	0253	

CT848TN	0253	
CVT2128	0509	
FX770E	0747	V4 or Higher RCU Required
FX880E	0747	V4 or Higher RCU Required
FX980E	0747	V4 or Higher RCU Required
PD5000	0772	V4 or Higher RCU Required
PW242PD7200	0747	V4 or Higher RCU Required
PWIL28LD5200E	0253	
R40A01	0662	V4 or Higher RCU Required
RC200	0772	V4 or Higher RCU Required
RM775E	0747	V4 or Higher RCU Required
U9G022131	0253	
VT880E	0747	V4 or Higher RCU Required
VTMX935E	0747	V4 or Higher RCU Required
VTRM800EV	0747	V4 or Higher RCU Required
W1L28LD5200E	0509	
W30	0747	V4 or Higher RCU Required
X877013	0173	

HITACHI FUJIAN

Model No	Codes	Notes
ALL	0604	V4 or Higher RCU Required
ALL	0136 0253	

HITSU

Model No	Codes	Notes
ALL	0037 0246	

HMV

Model No	Codes	Notes
ALL	0115 0221	

HOHER

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	1584	V6 or Higher RCU Required
ALL	0893	
H28T90	0742	V4 or Higher RCU Required

HOME ELECTRONICS

Model No	Codes	Notes
ALL	0634	V4 or Higher RCU Required

HONGMEI

Model No	Codes	Notes
ALL	0037 0292	

HONGYAN

Model No	Codes	Notes
ALL	0292 0440	

HORNYPHON

Model No	Codes	Notes
ALL	0065 0584 0040	

HOSHAI

Model No	Codes	Notes
ALL	0246 0310	

HUA TUN

Model No	Codes	Notes
ALL	0037	

HUAFA

Model No	Codes	Notes
ALL	0037	

HUANGHAIMEI

Model No	Codes	Notes
ALL	0037	

HUANGHE

Model No	Codes	Notes
ALL	0037	

HUANGLONG

Model No	Codes	Notes
ALL	0037	

HUANGSHAN

Model No	Codes	Notes
ALL	0037 0292 0440	

HUANYU

Model No	Codes	Notes
ALL	0402 0244	
ALL	0065 0255 0292	

HUAQIANG

Model No	Codes	Notes
ALL	0292 0440	

HUARI

Model No	Codes	Notes
ALL	0292 0440	
HUGOSON		
Model No	Codes	Notes
ALL	0918 1245	
HUMAX		
Model No	Codes	Notes
ALL	1323	
HYGASHI		
Model No	Codes	Notes
ALL	0245 0244	
HYPER		
Model No	Codes	Notes
ALL	0037 0244 0245 0275	
HYPERSONIC		
Model No	Codes	Notes
ALL	0389	
HYPSON		
Model No	Codes	Notes
ALL	696	
ALL	0696 0742 0743	V4 or Higher RCU Required
ALL	1936 1962	V6 or Higher RCU Required
ALL	0065 0292 0584 0310 0245 0266 0514	
NRR3099NBL	0743	V4 or Higher RCU Required

NRR55	0743	V4 or Higher RCU Required
NRR70N	0742	V4 or Higher RCU Required
V3600	0696	V4 or Higher RCU Required

HYUNDAI

Model No	Codes	Notes
ALL	0831 0893 1180 1272 1322 0904 1309 1584	
ALL	0065 0584	

IBERIA

Model No	Codes	Notes
ALL	0065 0584	

ICE

Model No	Codes	Notes
ALL	0245 0244 0246 0399 0065 0292 0037 0584	

ICES

Model No	Codes	Notes
ALL	0246 0244	

ICOS

Model No	Codes	Notes
ALL	0040	

ICT

Model No	Codes	Notes
ALL	0065 0584	
ALL	1165	

IDEAL

Model No	Codes	Notes
ALL	0065	
IDTV28N	0065	
IYAMA		

Model No	Codes	Notes
ALL	1245	
IMPERIAL		

Model No	Codes	Notes
ALL	0065 0102 0191 0275 0398 0446 0584 0389 0377 0224 0104 0459 0498 0559	
IMPERIAL CROWN		

Model No	Codes	Notes
ALL	0689	V6 or Higher RCU Required
ALL	0037 0292 0402 0440	
INDESIT		

Model No	Codes	Notes
ALL	0241 0339	
INDIANA		

Model No	Codes	Notes
ALL	0065 0584	
INFOCUS		

Model No	Codes	Notes
ALL	0764 0780 0809 0769 0766 1192 1234	
INGELEN		

Model No	Codes	Notes
ALL	0191 0515 0389	
ALL	0742	V4 or Higher RCU Required
GMUNDEN	0742	V4 or Higher RCU Required
HB55FUGEN	0742	V4 or Higher RCU Required
HB71TXT	0742	V4 or Higher RCU Required
HB7718HB	0742	V4 or Higher RCU Required

INGERSOLL

Model No	Codes	Notes
ALL	0037	

INNO HIT

Model No	Codes	Notes
ALL	1191	
ALL	0335	
ALL	0065 0037 0275 0104 0246 0100 0544 0245 0318 0103 0584 0310	

INNOVA

Model No	Codes	Notes
ALL	0065	

INNOVATION

Model No	Codes	Notes
ALL	0547 0065 0584	

INNOWERT

Model No	Codes	Notes
ALL	0893 1326	

INTEQ

Model No	Codes	Notes
ALL	0045	

INTERACTIVE

Model No	Codes	Notes
ALL	0065 0584 0040 0115 0540 0191 0574 0389 0398 0137	

INTERBUY

Model No	Codes	Notes
ALL	0037 0065 0292 0275 0540 0584	

INTERFUNK

Model No	Codes	Notes
ALL	0065 0191 0584 0040 0275 0115 0389 0540 0574 0398 0137 0377	

INTERNAL

Model No	Codes	Notes
ALL	1937	V6 or Higher RCU Required
ALL	0065 0584 0527 0402	
ALL	0652	V4 or Higher RCU Required
INT1472	0652	V4 ONLY RCU
INT2070	0652	V4 ONLY RCU
R35F28	0652	V4 ONLY RCU

INTERNATIONAL

Model No	Codes	Notes
ALL	0244	

INTERVISION

Model No	Codes	Notes
ALL	0065 0310 0245 0292 0399 0405 0547 0514 0398 0515 0246 0459 0191 0275 0037 0584	

IRRADIO

Model No	Codes	Notes
ALL	0037 0065 0584 0246 0275 0318 0104 0399	

IRT

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

ISUKAI

Model No	Codes	Notes
ALL	0246 0065 0584 0310	

ITC

Model No	Codes	Notes
ALL	0245	

ITS

Model No	Codes	Notes
ALL	0292 0310 0244 0399 0065 0246 0037 0584	

ITT

Model No	Codes	Notes
ALL	0576 0191 0574 0379 0207 0389 0221 0374 0508 0367 0377 0501 0236 0311 0572	
ALL	0035 0549	

ITT NOKIA

Model No	Codes	Notes
ALL	0508 0191 0374 0379 0501 0576 0389 0367 0207 0377 0236 0574 0659 0634 0391 0459	
ALL	0585 0549	

ITV

Model No	Codes	Notes
ALL	0292 0312 0065 0584 0275 0402	

JEAN

Model No	Codes	Notes
ALL	0064	
ALL	0502 0037 0207	

JEC

Model No	Codes	Notes
ALL	0063 0530	

JEG

Model No	Codes	Notes
ALL	0065	
CT7951GB	0065	

JIALICAI

Model No	Codes	Notes
ALL	0037 0292 0440	

JINFENG

Model No	Codes	Notes
----------	-------	-------

ALL 0236 0254

JINQUE

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292 0440

JINTA

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292 0440

JINXING

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292

ALL 0726 V4 or Higher RCU Required

JMB

Model No	Codes	Notes
----------	-------	-------

20T 0662 V4 or Higher RCU Required

3028WSS 0065

ALL 0662 V4 or Higher RCU Required

ALL 1936 V6 or Higher RCU Required

ALL 0065 0584 0527 0402 0471

G020T 0065

L701DX 0065

N028WSS 0065

V028WSS 0584

JNC

Model No	Codes	Notes
----------	-------	-------

ALL 1992

JUBILEE

Model No	Codes	Notes
ALL	0584	
JUHUA		

Model No	Codes	Notes
ALL	0292 0440	
JVC		

Model No	Codes	Notes
ALL	0081 0122 0033 0536 0671	
ALL	0681 0399 0221 0218 0634 0220 0064 0246 0446	
ALL	0711 0759	V4 or Higher RCU Required
ALL	0671	V4 or Higher RCU Required
AV215X1EK	0681	
AV21F1EK	0681	
AV21H1EK	0681	
AV21QT4SJ	0681	
AV21SX1EK	0681	
AV21TF4EK	0681	
AV24WT2EK	0681	
AV25F18K	0681	
AV25FIEK	0681	
AV25R370KE	0681	
AV25SX1EK	0681	
AV25SX2EK	0681	
AV25T5TEK	0681	
AV25TSIEK	0681	
AV25VM1EK	0681	
AV28CT1EK	0681	
AV28CT1SJF	0681	
AV28F1EK	0681	
AV28FEK	0681	
AV28GT1SJF	0681	

AV28R100EKS	0681
AV28R47SK	0681
AV28T25EK	0681
AV28T25EKS	0681
AV28T55EKS	0681
AV28T67SKE	0681
AV28T77SK	0681
AV28WFR1EK	0681
AV28WFT1EK	0681
AV28WFT1EKS	0681
AV28WR2EK	0681
AV28WR4EKS	0681
AV28WRZEK	0681
AV28WT2EK	0681
AV28WT4EK	0681
AV28WT5EKS	0681
AV28WX1EK	0681
AV28X35HKE	0681
AV290X1EK	0681
AV29FX2EK	0681
AV29SX2EK	0681
AV29W33	0681
AV32H77SK	0681
AV32P37SJE	0681
AV32R250EKS	0681
AV32R370KE	0681
AV32R47SK	0681
AV32T25EKS	0681
AV32T4BK	0681
AV32T4SK	0681
AV32T67	0681
AV32T67SKE	0681
AV32T77SK	0681
AV32WFT1EK	0681

AV32WL1EK	0681	
AV32WR4EK	0681	
AV32WR4EKS	0681	
AV32WX1EK	0681	
AV32X47HK	0681	
C1480EK	0681	
C21TX1SP	0681	
CM21773004	0681	
CM36224019E	0536	
GDV4210PZW	0759	V4 or Higher RCU Required
GDV4211	0759	V4 or Higher RCU Required
GVD425	0671	V4 ONLY RCU
LT23E31BJG	0681	
LT26C31BJE	0681	
LT32C31BJE	0681	
RMC556	0671	V4 ONLY RCU
RMC559	0671	V4 ONLY RCU
RMC575	0759	V4 or Higher RCU Required

KAIGE

Model No	Codes	Notes
ALL	0037 0292 0440	

KAISUI

Model No	Codes	Notes
ALL	0037 0246 0244 0310 0065 0245 0584	

KAMBROOK

Model No	Codes	Notes
ALL	0405 0459	

KAMP

Model No	Codes	Notes
ALL	0244	
KANGLI		

Model No	Codes	Notes
ALL	0037 0292 0402	
ALL	0689	V6 or Higher RCU Required
KANGYI		

Model No	Codes	Notes
ALL	0037 0292 0440	
KAPSCH		

Model No	Codes	Notes
ALL	0191 0389 0132	
KARCHER		

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	1584	V6 or Higher RCU Required
ALL	0065 0584 0398 0191 0310 0292	
KATHREIN		

Model No	Codes	Notes
ALL	0584 0065	
KAWA		

Model No	Codes	Notes
ALL	0399	

KAWASHO

Model No	Codes	Notes
ALL	0244	

KB ARISTOCRAT

Model No	Codes	Notes
ALL	0191	

KENDO

Model No	Codes	Notes
ALL	0065 0263 0390 0584 0191 0547 0540 0398 0405 0391 0275	

KENNEDY

Model No	Codes	Notes
ALL	0191	
ALL	0234 0241 0463	

KENNEX

Model No	Codes	Notes
ALL	1065	

KENWOOD

Model No	Codes	Notes
ALL	0133	

KIC

Model No	Codes	Notes
ALL	0245	

KINGSLEY

Model No	Codes	Notes
ALL	0244	

KIOTO

Model No	Codes	Notes
ALL	0584	

KISS

Model No	Codes	Notes
ALL	0828	

KITON

Model No	Codes	Notes
ALL	0584 0065	
ALL	0696	V4 or Higher RCU Required
ALL	1696	

KLL

Model No	Codes	Notes
ALL	0065	

KNEISSEL

Model No	Codes	Notes
ALL	0065 0398 0402 0527 0584 0266 0390	
ALL	1936	V6 or Higher RCU Required

KOLIN

Model No	Codes	Notes
ALL	0246	

ALL 0502 0136 0064

KOLSTER

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584 0377 0275

KONGQUE

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292

KONICHI

Model No	Codes	Notes
----------	-------	-------

ALL 0037

KONKA

Model No	Codes	Notes
----------	-------	-------

ALL 0399 0246 0065 0584 0446 0615

ALL 0742 V4 or Higher RCU Required

ALL 0696

TVC70SX2810 0742 V4 or Higher RCU Required

KONTAKT

Model No	Codes	Notes
----------	-------	-------

ALL 0515

KORPEL

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

KORTING

Model No	Codes	Notes
ALL	0115 0398	
KOSMOS		

Model No	Codes	Notes
ALL	0065 0584	
KOTRON		

Model No	Codes	Notes
ALL	0440 0292	
KOYODA		

Model No	Codes	Notes
ALL	0037	
KRAKING		

Model No	Codes	Notes
ALL	0266	
KRIESLER		

Model No	Codes	Notes
ALL	0040	
KTV		

Model No	Codes	Notes
ALL	0245	
KUAILE		

Model No	Codes	Notes
ALL	0037 0292 0440	

KUBA

Model No	Codes	Notes
ALL	0377 0191	

KUBA ELECTRONIC

Model No	Codes	Notes
ALL	0377 0191	

KULUN

Model No	Codes	Notes
ALL	0037	

KUNLUN

Model No	Codes	Notes
ALL	0236 0254 0292 0402	
ALL	0689	V6 or Higher RCU Required

KYOSHU

Model No	Codes	Notes
ALL	0060	
ALL	0440 0292 0446	

KYOTO

Model No	Codes	Notes
ALL	0060	
ALL	0191 0244 0245	

L&S ELECTRONIC

Model No	Codes	Notes
ALL	0893	

ALL	0742	V4 or Higher RCU Required
-----	------	---------------------------

LASAT

Model No	Codes	Notes
----------	-------	-------

ALL	0514 0398	
-----	-----------	--

LAVA VISION

Model No	Codes	Notes
----------	-------	-------

ALL	0065	
-----	------	--

LT30FLP	0065	
---------	------	--

LEADER

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

LECSON

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

ALL	0652	V4 or Higher RCU Required
-----	------	---------------------------

CTV900W	0065	
---------	------	--

TVCR914B	0652	V4 ONLY RCU
----------	------	-------------

TVCR914S	0652	V4 ONLY RCU
----------	------	-------------

LEGEND

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0365	
-----	-----------	--

LENCO

Model No	Codes	Notes
----------	-------	-------

ALL	0749	
-----	------	--

ALL	0065 0037 0191 0402 0584 0132 0502 0615	
-----	---	--

LENOIR

Model No	Codes	Notes
ALL	0037	

LESA

Model No	Codes	Notes
ALL	0275	

LEVIS AUSTRIA

Model No	Codes	Notes
ALL	0065 0584	

LEXSOR

Model No	Codes	Notes
ALL	1224	

LEYCO

Model No	Codes	Notes
ALL	0065 0292 0100 0584 0322 0607	

LG

Model No	Codes	Notes
28CB10RX	0742	V4 or Higher RCU Required
28CZ10RX	0742	V4 or Higher RCU Required
3828VA0191D	0065	
ALL	0206 1206 1293 0851 0857 1665 1174 1176 1219 1280	
ALL	0065 0244 0405 0318 0037 0398 0191 0459 0245 0584 0137 0634	
ALL	0726 0742 0743	V4 or Higher RCU Required
ALL	1962	V6 or Higher RCU Required

ALL	0389 0060 0275 0502 0136 0508 0672	
C114E20	0065	
CB14F80X	0743	V4 or Higher RCU Required
CB14F84	0742	V4 or Higher RCU Required
CB20F84X	0742	V4 or Higher RCU Required
CB21TUOX	0726	V4 or Higher RCU Required
CD29Q10ET	0065	
CE29Q10ET	0508	
CF21A50F	0065	
CI14F80	0743	V4 or Higher RCU Required
NRC120F080F	0065	
NRCB14F84TX	0742	V4 or Higher RCU Required
NRI28CZ10RX	0742	V4 or Higher RCU Required
NRR132CZ10RX	0742	V4 or Higher RCU Required
NRR1-32CZ10RX	0742	V4 or Higher RCU Required
R132CZ10RX	0742	V4 or Higher RCU Required
RE28FZ10PX	0584	
RE32FZ10PX	0584	
RI28CZ10RX	0742	V4 or Higher RCU Required
RI32CZ10RX	0742	V4 or Higher RCU Required
RI32CZ10RX	0742	V4 or Higher RCU Required
WF32A14T	0065	

LIESSENK & TTER

Model No	Codes	Notes
ALL	0065 0584	

LIESSENKOTTER

Model No	Codes	Notes
ALL	0065 0040 0584	

LIFETEC

Model No	Codes	Notes
----------	-------	-------

1530	0696	V4 or Higher RCU Required
7301	0683	V4 or Higher RCU Required
ALL	0065 0037 0547 0402 0540 0584 0246 0292	
ALL	0671	V4 or Higher RCU Required
ALL	1065 1165 1276	
ALL	0683 0696 0711	V4 or Higher RCU Required
LT3733V8	0696	V4 or Higher RCU Required
LT3733VT	0696	V4 or Higher RCU Required
LT3734	0696	V4 or Higher RCU Required
LT3734VT	0696	V4 or Higher RCU Required
LT3739VT	0696	V4 or Higher RCU Required

LLOYDS

Model No	Codes	Notes
ALL	0037	

LLOYTRON

Model No	Codes	Notes
ALL	0060	

LME

Model No	Codes	Notes
ALL	0459	

LODOS

Model No	Codes	Notes
ALL	0065	
ALL	1065 1177	
RF2100TV	0065	
X28	0065	

LOEWE

Model No	Codes	Notes
ALL	0164	
ALL	0683	V4 or Higher RCU Required
ALL	0540 0115 0065 0398 0103 0661 0584 0390 0544	
PLANUS4672ZP	0683	V4 or Higher RCU Required

LOGIK

Model No	Codes	Notes
ALL	0908 1245 1065	
ALL	0696	V4 or Higher RCU Required
ALL	0221 0033 0061	
ALL	0039 0037 0292 0399	
ALL	0726	V4 or Higher RCU Required
LK74	0726	V4 or Higher RCU Required

LOGIX

Model No	Codes	Notes
ALL	1696	
ALL	0547	
LTV3601	0696	V4 or Higher RCU Required
RC223	0696	V4 or Higher RCU Required

LONGJIANG

Model No	Codes	Notes
ALL	0292 0440	

LUCKY GOLDSTAR

Model No	Codes	Notes
ALL	PLEASE USE LG CODES	

LUMA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0391 0191 0584 0402 0037 0390	
-----	------------------------------------	--

LUMATRON

Model No	Codes	Notes
----------	-------	-------

ALL	0101 0391 0245 0390 0292 0389 0065 0191 0584	
-----	--	--

ALL	0287 0234	
-----	-----------	--

LUX MAY

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0037 0584 0609	
-----	---------------------	--

LUXMAN

Model No	Codes	Notes
----------	-------	-------

ALL	0607	
-----	------	--

LUXOR

Model No	Codes	Notes
----------	-------	-------

ALL	0191 0374 0318 0222 0576 0377 0384 0389 0508 0236 0391 0245 0659 0574 0207 0501	
-----	--	--

ALL	1191 1065	
-----	-----------	--

LXI

Model No	Codes	Notes
----------	-------	-------

ALL	0206	
-----	------	--

LYETEC

Model No	Codes	Notes
----------	-------	-------

ALL	0065	
-----	------	--

LT7055VTST	0065	
------------	------	--

MADISON

Model No	Codes	Notes
ALL	0065 0584	

MAGNADYNE

Model No	Codes	Notes
ALL	0115 0275 0544 0103 0572 0191	

MAGNAFON

Model No	Codes	Notes
ALL	0544 0103 0104 0244 0101	

MAGNAVOX

Model No	Codes	Notes
ALL	0065 0584 0064 0207	

MAGNUM

Model No	Codes	Notes
7065VTSTEREO	0742	V4 or Higher RCU Required
ALL	1317	
ALL	0065 0584	
ALL	0742 0743	V4 or Higher RCU Required
TV065VTSTEREO	0742	V4 or Higher RCU Required
TV5545VT	0743	V4 or Higher RCU Required

MANDOR

Model No	Codes	Notes
ALL	0292	

MANESTH

Model No	Codes	Notes
ALL	0065 0245 0263 0584 0292 0304 0063 0322 0191 0391	

MANHATTAN

Model No	Codes	Notes
ALL	0065 0584 0191	
ALL	0696	V4 or Higher RCU Required
ALL	0904 1065 1295 0806 1696	
MT3753	0696	V4 or Higher RCU Required

MARANTZ

Model No	Codes	Notes
ALL	0065 0584 0440	
ALL	0882	

MARELLI

Model No	Codes	Notes
ALL	0115	

MARK

Model No	Codes	Notes
ALL	0244 0245 0402 0065 0037 0584	
ALL	0742 0743	V4 or Higher RCU Required
TBT2002TXT	0743	V4 or Higher RCU Required
TBT2830NT	0742	V4 or Higher RCU Required

MASTERS

Model No	Codes	Notes
ALL	0527 0065	

MASUDA

Model No	Codes	Notes
ALL	0246 0399 0037 0292 0065 0245 0584	

MATSUI

Model No	Codes	Notes
1408R	0219	
14R1	0065	
14V1T	0223	
14VIC	0065	
14VIR	0223	
14VIT	0223	
20T10	0742	V4 or Higher RCU Required
20V1T	0223	
20VIR	0223	
20Z1T	0219	
2107NS	0471	
2107T	0471	
2160	0263	
2199N	0471	
219T	0263	
21N1	0515	
21N1	0065	
21V1N	0223	
2528N03	0065	
25M1MK2	0236	
25N10	0065	
280W01	0471	
2899N	0263	
28DW01	0471	
28M2	0236	
28MI	0263	

28N03	0065	
28N10	0065	
28ND3	0065	
28WF10	0742	V4 or Higher RCU Required
28WN	0219	
28WN04	0471	
28WN05	0471	
28WN20	0065	
28WV2N	0219	
28WVDP	0219	
32WN03	0065	
32WN20TV	0065	
32WV2DP	0219	
42P900	0471	
522889	0219	
	0263 0205 0037 0383 0065 0471 0039 0100 0515	
	0239 0245 0382 0322 0461 0300 0607 0544 0399	
ALL	0063 0297 0498 0391 0459 0103 0219 0363 0285	
	0584 0064 0236 0073 0191 0616 0377 0223 0572	
	0657	
ALL	0742	V4 or Higher RCU Required
ALL	1936	V6 or Higher RCU Required
ALL	0061 0483 0055	
ALL	1065	
R120G1000	0515	
TVR162S	1936	V6 or Higher RCU Required
TVR180	1936	V6 or Higher RCU Required
TVR185	1936	V6 or Higher RCU Required
TVR190	1936	V6 or Higher RCU Required
TVR2000 (SIL)	1936	V6 or Higher RCU Required
WV2DP	0219	

MATSUSHITA

Model No	Codes	Notes
ALL	0678	

MATSUVIAMA

Model No	Codes	Notes
ALL	0615	

MAXAM

Model No	Codes	Notes
ALL	0292	

MAXIM

Model No	Codes	Notes
1151	0065	
1152	0065	
ALL	0065	
ALL	1584	V6 or Higher RCU Required

MAXIVIDEO

Model No	Codes	Notes
ALL	0816 0817	

MCE

Model No	Codes	Notes
ALL	0037	

MCMICHAEL

Model No	Codes	Notes
ALL	0071	

MEDIATOR

Model No	Codes	Notes
ALL	0040 0065 0584	

MEDION

Model No	Codes	Notes
3731VT	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	0696 0726	V4 or Higher RCU Required
ALL	1936 1928	V6 or Higher RCU Required
ALL	0065 0547 0540 0584 0273	
ALL	0724	
ALL	0836 1165 1065 1465 1276 1696 1249 0908 1317	
MD3702	0726	V4 or Higher RCU Required
MD3729	0696	V4 or Higher RCU Required
MD3731	0696	V4 or Higher RCU Required
ND3729	0696	V4 or Higher RCU Required

MEGATRON

Model No	Codes	Notes
ALL	0206	

MEI

Model No	Codes	Notes
ALL	0065 0584	
ALL	1065	

MEILE

Model No	Codes	Notes
ALL	0292 0440	

MELECTRONIC

Model No	Codes	Notes
ALL	0689	V6 or Higher RCU Required
ALL	0662	V4 or Higher RCU Required

ALL	0037 0374 0065 0540 0132 0137 0371 0191 0275 0133 0245 0315 0402 0508 0244 0377 0584 0389 0219 0223	
MTS2100DW135	0662	V4 or Higher RCU Required
R40A01	0662	V4 or Higher RCU Required

MEMOREX

Model No	Codes	Notes
ALL	0206	
ALL	0178 0182 0278 0207	
ALL	0037	

MEMPHIS

Model No	Codes	Notes
ALL	0365 0100 0037	

MERCURY

Model No	Codes	Notes
ALL	0065 0037 0584	

MERRITT

Model No	Codes	Notes
ALL	0576 0389 0191	

METRONIC

Model No	Codes	Notes
ALL	0653	

METZ

Model No	Codes	Notes
ALL	0475 0563 0395 0115 0223 0219 0065 0584 0615	
ALL	0774 1191 1065 1696	

ALL	0696	V4 or Higher RCU Required
FLORIDA37TC31	0696	V4 or Higher RCU Required
FLORIDAVT31TC31	0696	V4 or Higher RCU Required
RC10	0696	V4 or Higher RCU Required
RC19	0696	V4 or Higher RCU Required

MGA

Model No	Codes	Notes
ALL	0206	
ALL	0065 0584 0246 0132	

MICROMAXX

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
ALL	1065 0836 1696	
ALL	0065 0584	
MM3742	0696	V4 or Higher RCU Required

MICROSTAR

Model No	Codes	Notes
ALL	0836	

MIDLAND

Model No	Codes	Notes
ALL	0045	

MIKOMI

Model No	Codes	Notes
ALL	1177	
ALL	0065	
CTV20TX36	0065	
CTV21TX30	0065	

LCD1701W 0065

MINATO

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

MINERVA

Model No	Codes	Notes
----------	-------	-------

ALL	0104 0223 0515 0563 0219 0098 0544 0136	
-----	---	--

ALL	0582 0335	
-----	-----------	--

MINOKA

Model No	Codes	Notes
----------	-------	-------

ALL	0397	
-----	------	--

ALL	0387 0440 0065 0584	
-----	---------------------	--

MIRROR

Model No	Codes	Notes
----------	-------	-------

ALL	1928	V6 or Higher RCU Required
-----	------	---------------------------

MISTRAL ELECTRONICS

Model No	Codes	Notes
----------	-------	-------

ALL	0221	
-----	------	--

mitsubishi

Model No	Codes	Notes
----------	-------	-------

25A1LS	0540	
--------	------	--

ALL	0035 0178 0061 0121 0502 0207 0150	
-----	------------------------------------	--

ALL	1307 0206 1065 0896	
-----	---------------------	--

ALL	1962	V6 or Higher RCU Required
-----	------	---------------------------

ALL	0719	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0136 0382 0064 0221 0065 0540 0115 0563 0229 0386 0584 0236	
BD28S	0540	
BD32WS	0540	
C25B7B	0136	
C25S7B	0136	
C28S7B	0136	
CT15MSITX	0136	
CT2146TX	0136	
CT21ASSTX	0136	
CT21AV1B	0136	
CT21AV1V	0136	
CT21M2TX	0136	
CT21M3TX	0136	
CT21M5BT	0136	
CT21STX	0136	
CT23A3STX	0136	
CT2525TX	0136	
CT25A2STX	0136	
CT25A3STXP	0136	
CT25A4STX	0136	
CT25AV1B	0136	
CT25M2TX	0136	
CT25M3TX	0136	
CT25M5BT	0136	
CT25S7B	0136	
CT2617TX	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
CT28AV1B	0136	
CT28C7B	0136	
CT29A4STX	0136	
CT33B3STX	0136	
XP4015C	0719	V4 or Higher RCU Required

MITSURI GENERAL

Model No	Codes	Notes
ALL	0191	
MIVAR		

Model No	Codes	Notes
ALL	0244 0318 0544 0398 0104 0245	
MONACO		

Model No	Codes	Notes
ALL	0037	
MORGANS		

Model No	Codes	Notes
ALL	0065 0584	
MOTION		

Model No	Codes	Notes
ALL	0104	
MTC		

Model No	Codes	Notes
ALL	0088	
ALL	0377 0244 0540 0398 0191 0389	
MTEC		

Model No	Codes	Notes
ALL	0300	
ALL	0060	
MTLOGIC		

Model No	Codes	Notes
ALL	1336	
ALL	0742	V4 or Higher RCU Required

MUDAN

Model No	Codes	Notes
ALL	0037 0236 0254 0292 0440	

MULTI BROADCAST

Model No	Codes	Notes
ALL	0221	

MULTIMAT

Model No	Codes	Notes
ALL	0460	

MULTISTANDARD

Model No	Codes	Notes
ALL	0460	

MULTITEC

Model No	Codes	Notes
ALL	1584	V6 or Higher RCU Required
ALL	1065 1696	
ALL	0696	V4 or Higher RCU Required
ALL	0065 0584 0514	
CTV1400	0696	V4 or Higher RCU Required

MULTITECH

Model No	Codes	Notes
----------	-------	-------

ALL 0244 0275 0377 0037 0103 0065 0514 0391 0398
0245 0584 0292 0104

ALL 0130

MURPHY

Model No Codes Notes

ALL 0132 0244 0191 0502 0100 0229 0379

MUSIKLAND

Model No Codes Notes

ALL 0065 0246 0275 0584

MYCOM

Model No Codes Notes

ALL 0206

MYRYAD

Model No Codes Notes

ALL 0584 0065

NAD

Model No Codes Notes

ALL 0206

ALL 0194 0389 0191

NAGOA

Model No Codes Notes

ALL 0311

NAIKO

Model No Codes Notes

ALL 0065 0634 0584

NAKIMURA

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0402 0584

NANBAO

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292 0440

NANSHENG

Model No	Codes	Notes
----------	-------	-------

ALL 0292 0440

NAONIS

Model No	Codes	Notes
----------	-------	-------

ALL 0391 0191

NAT

Model No	Codes	Notes
----------	-------	-------

ALL 0254 0242

NATIONAL

Model No	Codes	Notes
----------	-------	-------

ALL 0254 0242

ALL 0368 0236 0255

NEC

Model No	Codes	Notes
----------	-------	-------

ALL 1298 1732 0799 1398 1163 0910

ALL	0483 0348 0502 0292 0440 0536	
ALL	0037 0402 0245 0065 0064 0198 0615 0525 0584 0039 0273 0527	
ALL	0689	V6 or Higher RCU Required
ALL	0732	V4 or Higher RCU Required
MT1050	0732	V4 or Higher RCU Required
PLASMASYNC4210W	0732	V4 or Higher RCU Required
PLASMASYSNC42MPZ	0732	V4 or Higher RCU Required
PX42VM2G	0732	V4 or Higher RCU Required
PX42VM3G	0732	V4 or Higher RCU Required
RD327	0732	V4 or Higher RCU Required
RD337	0732	V4 or Higher RCU Required

NECKERMANN

Model No	Codes	Notes
ALL	1533 1038	V6 or Higher RCU Required
ALL	0065 0219 0398 0584 0533 0038 0191 0446 0377 0115 0275 0245 0391 0540	

NEI

Model No	Codes	Notes
2031TX	0459	
2131TX	0459	
ALL	0065 0365 0584 0459 0399 0191	
EI4D1X	0065	

NEOVIA

Model No	Codes	Notes
ALL	1234 0893 1992 0904	

NESCO

Model No	Codes	Notes
ALL	1936	V6 or Higher RCU Required

ALL	0207 0275	
-----	-----------	--

NETSAT

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

NETWORK

Model No	Codes	Notes
----------	-------	-------

ALL	0365	
-----	------	--

ALL	0060	
-----	------	--

NEUFUNK

Model No	Codes	Notes
----------	-------	-------

ALL	0584 0037 0065 0246 0310	
-----	--------------------------	--

ALL	0742	V4 or Higher RCU Required
-----	------	---------------------------

TV167001	0742	V4 or Higher RCU Required
----------	------	---------------------------

NEW TECH

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0037 0584 0371 0245	
-----	--------------------------	--

NEW WORLD

Model No	Codes	Notes
----------	-------	-------

ALL	0246	
-----	------	--

NEWAVE

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0311	
-----	-----------	--

NFREN

Model No	Codes	Notes
ALL	0828	V4 or Higher RCU Required

NICAM

Model No	Codes	Notes
ALL	0572	

NICAMAGIC

Model No	Codes	Notes
ALL	0244	
ALL	0311	

NIKKAI

Model No	Codes	Notes
ALL	0064 0037 0245 0063 0065 0100 0244 0246 0292 0365 0584	
ALL	0060	

NIKKEI

Model No	Codes	Notes
ALL	0742	

NIKKO

Model No	Codes	Notes
ALL	0345	
ALL	0206	

NISHI

Model No	Codes	Notes
ALL	0510	

NOBLIKO

Model No	Codes	Notes
ALL	0244 0098 0104	
ALL	0130	

NOGAMATIC

Model No	Codes	Notes
ALL	0137 0224	

NOKIA

Model No	Codes	Notes
ALL	0508 0501 0576 0379 0236 0402 0387 0389 0367 0574 0377 0374 0191 0634 0659 0207 0137	
ALL	0035 0585	
FB72B2	0508	
SFN5515	0374	
SP71K1	0508	

NORDIC

Model No	Codes	Notes
ALL	0245	

NORDMENDE

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	0137 0224 0371 0315 0226 0223 0588 0065 0584 0363 0191 0499	
ALL	0339 0241 0427	
ALL	1287	
NRF2108T	0742	V4 or Higher RCU Required
NTV20100T	0742	V4 or Higher RCU Required

NVTV1452	0742	V4 or Higher RCU Required
----------	------	---------------------------

NORFOLK

Model No	Codes	Notes
----------	-------	-------

ALL	0191	
-----	------	--

NORMEREL

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

NOVAK

Model No	Codes	Notes
----------	-------	-------

ALL	0040 0065 0584	
-----	----------------	--

NOVATRONIC

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0133 0402 0559 0584	
-----	--------------------------	--

NURNBERG

Model No	Codes	Notes
----------	-------	-------

ALL	0191 0389	
-----	-----------	--

NUTEC

Model No	Codes	Notes
----------	-------	-------

ALL	0726	V4 or Higher RCU Required
-----	------	---------------------------

NTT321A	0726	V4 or Higher RCU Required
---------	------	---------------------------

OCEANIC

Model No	Codes	Notes
----------	-------	-------

ALL	0191 0389 0322 0236 0591 0501 0576 0508	
-----	---	--

ODEON

Model No	Codes	Notes
ALL	0292	

OKANO

Model No	Codes	Notes
ALL	0398 0065 0584 0292 0100 0516 0037	

OMEGA

Model No	Codes	Notes
ALL	0292	

OMNI

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

ONIMAX

Model No	Codes	Notes
ALL	NO CODES AVAILABLE - COULD ALSO TRY PACIFIC CODES AS THEY HAVE THE SAME MODEL NUMBERS	

ONWA

Model No	Codes	Notes
ALL	0246 0399 0461 0609 0459 0630	
K9228	0461	

OPERA

Model No	Codes	Notes
ALL	0065 0584	

OPTIMUS

Model No	Codes	Notes
ALL	0194 0678	

ORBIT

Model No	Codes	Notes
ALL	0065 0584	

ORION

Model No	Codes	Notes
284DL	0683	V4 or Higher RCU Required
284FC	0683	V4 or Higher RCU Required
287CE	0683	V4 or Higher RCU Required
7000	0683	V4 or Higher RCU Required
ALL	0053 0348 0054 0130 0345	
ALL	0322 0383 0263 0205 0039 0065 0349 0392 0544 0037 0502 0239 0584 0297 0471 0505 0207 0292 0440 0559 0572	
ALL	0683 0742	V4 or Higher RCU Required
ALL	1936	V6 or Higher RCU Required
ALL	0908 1224	
ATSEUROPLUS	0683	V4 or Higher RCU Required
CTW7300	0683	V4 or Higher RCU Required
GV850	0683	V4 or Higher RCU Required
NR5177TXSI	0742	V4 or Higher RCU Required
NR5177XSI	0742	V4 or Higher RCU Required
NRTV897	0742	V4 or Higher RCU Required
OTTO8295PIP	0683	V4 or Higher RCU Required
TRIADE28	0683	V4 or Higher RCU Required
TRIADE34	0683	V4 or Higher RCU Required
TRIADE4300	0683	V4 or Higher RCU Required
TV2807	0683	V4 or Higher RCU Required
TV2810	0683	V4 or Higher RCU Required

TV2840	0683	V4 or Higher RCU Required
TV5177SI	0742	V4 or Higher RCU Required
TV8250	0683	V4 or Higher RCU Required

ORLINE

Model No	Codes	Notes
ALL	0065 0246 0584	

ORMOND

Model No	Codes	Notes
ALL	0065 0584	
ALL	0696	V4 or Higher RCU Required
ALL	1065 1696	
OR1498L	0696	V4 or Higher RCU Required

ORSOWE

Model No	Codes	Notes
ALL	0544	

OSAKI

Model No	Codes	Notes
ALL	0616 0100 0300 0292 0402 0502 0245 0521 0297 0246 0304 0285 0060 0065 0440 0239 0383 0584	
CI5013T	0065	

OSIO

Model No	Codes	Notes
ALL	0065 0584 0318	

OSO

Model No	Codes	Notes
----------	-------	-------

ALL	0246	
-----	------	--

OSUME

Model No	Codes	Notes
----------	-------	-------

ALL	0502 0060 0246 0064 0100 0185 0065 0584	
-----	---	--

OTAKE

Model No	Codes	Notes
----------	-------	-------

ALL	0345	
-----	------	--

OTIC

Model No	Codes	Notes
----------	-------	-------

ALL	1231	
-----	------	--

OTTO VERSAND

Model No	Codes	Notes
----------	-------	-------

ALL	0064 0065 0533 0245 0038 0371 0540 0563 0584 0223 0572 0377 0219 0389 0263 0137 0322 0254 0275 0037 0310 0459 0544 0547	
-----	---	--

ALL	1533 1038	V6 or Higher RCU Required
-----	-----------	---------------------------

PACE

Model No	Codes	Notes
----------	-------	-------

ALL	1936	V6 or Higher RCU Required
-----	------	---------------------------

PACIFIC

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0471	
-----	----------------	--

ALL	165 1265 1065	
-----	---------------	--

ALL	0733 0743	
-----	-----------	--

ALL	0742	V4 or Higher RCU Required
-----	------	---------------------------

ALL	1963	V6 or Higher RCU Required
-----	------	---------------------------

AP3210WNS	0742	V4 or Higher RCU Required
NRPTV5103	0742	V4 or Higher RCU Required
PDVTV14/100 (B)	1963	V6 or Higher RCU Required
PDVTV14100	1963	V6 or Higher RCU Required
PTV3605	0733	V4 or Higher RCU Required
PTV3606	0742	V4 or Higher RCU Required
PTV3606 (B)	0742	V4 or Higher RCU Required
PTV5102	0584	
PTV5103	0733	V4 or Higher RCU Required
PTV5103	0742	V4 or Higher RCU Required
PTV5103T	0743	V4 or Higher RCU Required
PTV6024	0065	
PTV8001T	0065	
PTV8001T76630	0584	
PTV8004T	0733	V4 or Higher RCU Required
PTV8005T	0733	V4 or Higher RCU Required
PTV8017	0584	
STT2021	0743	V4 or Higher RCU Required

PACKARD BELL

Model No	Codes	Notes
ALL	0065	
LCD20UK	0065	

PAEL

Model No	Codes	Notes
ALL	0244	

PALLADIUM

Model No	Codes	Notes
284DE	0683	V4 or Higher RCU Required
32DPB	0683	V4 or Higher RCU Required
765/390	0683	V4 or Higher RCU Required

765/392	0683	V4 or Higher RCU Required
772/542	0683	V4 or Higher RCU Required
8000	0683	V4 or Higher RCU Required
ALL	0683 0742	V4 or Higher RCU Required
ALL	1165	
ALL	1533 1038	V6 or Higher RCU Required
ALL	0398 0446 0065 0219 0533 0038 0584 0275 0377 0115 0191 0245 0547 0391	

PALSONIC

Model No	Codes	Notes
5160G	0733	V4 or Higher RCU Required
6150G	0733	V4 or Higher RCU Required
6820PF	0733	V4 or Higher RCU Required
811Q	0733	V4 or Higher RCU Required
ALL	1165	
ALL	0292 0065 0312 0440 0245 0405 0246 0584 0516 0446	
ALL	0726	V4 or Higher RCU Required
ALL	0733	
RCR110A	0733	V4 or Higher RCU Required

PANAMA

Model No	Codes	Notes
ALL	0275 0245 0244 0292 0065 0037 0584	

PANASONIC

Model No	Codes	Notes
24DX1	0678	
28PS67TT	0742	V4 or Higher RCU Required
32DTZ	0678	
32PD30	0678	
4DA	0678	

ALL	1678 0799 1238 1338	
ALL	0742	V4 or Higher RCU Required
ALL	0678 0254 0242 0191 0302 0544 0065 0395 0379 0389 0103 0576 0136 0584 0490	
ALL	0278 0154 0368 0128 0241 0236 0255 0536 0650	
ALL	0878 0881	V6 or Higher RCU Required
TC2153R	0278	
TC21L3PX	0678	
TH37PA20B	0678	
TH37PE30	0678	
TH37PE30B	0678	
TH37PE40B	0678	
TH37PV500B	0678	
TH37PW5	0678	
TH37PW7BXJ	0678	
TH42PA20B	0678	
TH42PE30	0678	
TH42PE30B	0678	
TH42PE40B	0254	
TH42PE50	0678	
TH42PE50B	0678	
TH42PV500B	0678	
TH42PW5	0678	
TH42PW7	0678	
TH42PWD6	0678	
TH50PV30	0678	
TH50PV30B	0678	
TX14GV1	0678	
TX15LT2	0678	
TX20LA1	0678	
TX2132V	0678	
TX2151	0278	
TX21512	0678	
TX2151T	0278	
TX2151TBH	0678	

TX2153T	0678
TX215521	0136
TX21612	0254
TX21AD2	0678
TX21CK1	0678
TX21GV1	0678
TX21JT2	0678
TX21M1T	0678
TX21M1TBK	0278
TX21M2T	0678
TX21MD1	0678
TX21MD1/B	0678
TX21MD3	0678
TX21MD41	0678
TX21MK1	0678
TX21MK1M	0678
TX21ND4	0678
TX21S1T	0678
TX21T1	0254
TX21V1	0254
TX21V2	0678
TX21V2BC	0678
TX22LT2	0678
TX22LT3	0678
TX2471	0254
TX2482	0254
TX24A1	0254
TX24DX1	0678
TX24PS1	0678
TX24PS2	0678
TX25A2X	0678
TX25AD1	0678
TX25AD2	0678
TX25AD2DP	0678

TX25CK1	0678
TX25G1	0678
TX25LD4DP	0678
TX25MD1	0678
TX25MD1B	0678
TX25MD1M	0678
TX25MD3	0678
TX25MD4	0678
TX25MK1	0678
TX25T2K	0254
TX25W2	0678
TX25X1BC	0678
TX25X1DL	0678
TX25XIBC	0678
TX26LXD1	0678
TX26LXD50	0678
TX26LXD52	0678
TX28A1	0678
TX28A2	0678
TX28CK1	0678
TX28DK1	0678
TX28DK2	0678
TX28DT2	0678
TX28DT30	0678
TX28DT4	0678
TX28DTM1	0678
TX28DTX1	0678
TX28G1	0678
TX28LD1	0678
TX28LD16B	0678
TX28MD3	0678
TX28MD4	0678
TX28MK1L	0678
TX28PB50	0678

TX28PK	0678
TX28PK1	0678
TX28PK3	0678
TX28PL1	0678
TX28PL10	0678
TX28PL4	0678
TX28PL4C	0678
TX28PM1	0678
TX28PM11	0678
TX28PN1	0678
TX28PN11	0678
TX28PS	0678
TX28PS1	0678
TX28PS12	0678
TX28PS12C	0678
TX28PS500	0678
TX28W2	0678
TX28X1	0678
TX28X1DP	0678
TX29A3	0678
TX29AD1DP	0678
TX29AD2	0678
TX29AD2DP	0678
TX32	0678
TX32DH40	0678
TX32DK1	0678
TX32DT2	0678
TX32DT30	0678
TX32DT4	0678
TX32DTX1	0678
TX32LXD1	0678
TX32LXD50	0678
TX32LXD500	0678
TX32LXD52	0678

TX32PB50	0678
TX32PF10	0678
TX32PG50	0678
TX32PK1	0678
TX32PK2	0678
TX32PK20	0678
TX32PL1	0678
TX32PL10	0678
TX32PLI	0650
TX32PM1	0678
TX32PM11	0678
TX32PM12	0678
TX32PS1	0678
TX32PS12	0678
TX32PS5	0678
TX32T5S	0678
TX32TF1	0678
TX33A1G	0678
TX36D3DT	0678
TX36DT30	0678
TX36PB50	0678
TX36PD30	0678
TX36PF10	0678
TX36PL32	0678
TX47PT1	0678
TXBW28D20P	0278
TXW28D2DP	0678
TXW28R3	0678
TXW28R3DP	0678
TXW28R4	0678
TXW28R4DP	0678
TXW32D2	0678
TXW32D2DP	0678
TXW32R	0678

TXW32R4	0678	
---------	------	--

TXW32R4DP	0678	
-----------	------	--

PANAVISION

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

PANDA

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0236 0254 0292 0440 0536	
-----	-------------------------------	--

ALL	0726	V4 or Higher RCU Required
-----	------	---------------------------

PAPOUW

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

PATHE CINEMA

Model No	Codes	Notes
----------	-------	-------

ALL	0191 0244 0266 0377 0459 0398	
-----	-------------------------------	--

PATHE MARCONI

Model No	Codes	Notes
----------	-------	-------

ALL	0137 0224 0226	
-----	----------------	--

PAUSA

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

PERDIO

Model No	Codes	Notes
----------	-------	-------

ALL 0348
 ALL 0065 0191 0297 0100 0244 0310 0584

PERFEKT

Model No	Codes	Notes
ALL	0065 0584	

PHASE

Model No	Codes	Notes
ALL	0060	

PHILCO

Model No	Codes	Notes
ALL	0280 0241 0112 0173 0502 0509	
ALL	0065 0280 0446 0275 0191 0115 0104 0398 0102 0584 0547	

PHILEX

Model No	Codes	Notes
ALL	0221 0229 0191 0379	

PHILHARMONIC

Model No	Codes	Notes
ALL	0245	

PHILIPS

Model No	Codes	Notes
140PV303/07	0584	
14PT1563/05F	0584	
14PT3685/05	0584	
14PT6107/05	0584	

14PV110/07	0584
14PV20007	0584
17PF9945	0584
20PV164/05	0065
20PV230/07	0065
21GR2550/058	0584
21GR2554/05B	0584
21PT161A105	0584
21PT161B-05	0584
21PT166A/03	0584
21PT4456/05	0584
21PT4456/06	0584
21PT4457/05	0584
21PT4475/05	0584
21PT532A05	0584
21PT5505	0584
23PF99445/12	0584
23PF9945/12	0584
23PF9946/12	0584
24PW6005	0584
24PW6005/05	0584
24PW6006	0584
24PW6006/05	0584
24PW6322/05	0584
24PW632405R	0065
24PW6518	0065
25PT4457/05	0584
25PT4475/05	0065
25PT4523/05	0065
25PT727B/05	0584
25ST1761	0584
28CL6770	0584
28CL6770/25Z	0584
28DW6558	0584

28DW6559/05	0584
28MD12E	0584
28PT/4523/25	0584
28PT4418/05	0584
28PT4456/05	0584
28PT4457/05	0584
28PT4521	0584
28PT482	0584
28PW5324/05	0065
28PW6005/05	0584
28PW6006	0584
28PW6006/05	0584
28PW6008	0584
28PW6008/05	0584
28PW6305	0584
28PW6305/05	0584
28PW6315	0065
28PW6322/05	0584
28PW6332	0584
28PW6506/05	0584
28PW6515	0584
28PW6515/05	0584
28PW6516/05	0065
28PW6517/05	0065
28PW6518	0584
28PW6518/05	0584
28PW6520	0584
28PW6606	0584
28PW8719/05	0584
28PW9308	0584
28WVRN	0584
29PT6773	0584
29PT6773/5	0584
29PT828C/05	0584

29PT828C/25	0065
29PT9113-05	0065
30PF9946	0584
30PF9975	0584
30PF9975/12	0584
32BW6332/25	0584
32FD9944/01	0584
32PF99445/12	0584
32PF9976/12	0584
32PF9986/12	0584
32PW5407/25	0065
32PW6006/25	0065
32PW6008	0584
32PW6008/05	0584
32PW631S	0065
32PW6322/25	0065
32PW632205	0584
32PW6332/25	0584
32PW6506	0584
32PW6506/05	0584
32PW6515	0584
32PW6515/05	0584
32PW6517	0065
32PW6518	0584
32PW6518/05	0584
32PW6526/05	0065
32PW6618/05	0584
32PW8515/05	0584
32PW9308	0584
32PW95203/05	0584
32PW9523/05	0584
32PW9523/25	0584
32PW952505,	0584
32PW9525C	0584

32PW9527	0584
32PW9566/05R	0584
32PW9586/05	0584
32PW9615/05	0584
32PW962B	0065
32TW6517	0584
32TW6518	0584
32VW6005	0065
37PF5520D	0584
37PF5520D10	0584
42PF7520D	0584
42PF9945	0584
42PF9945/12	0584
42PF9946	0584
42PF9946/12	0584
ALL	0749 0800 1274 1784 0718 1332
ALL	0584 0065 0040 0221 0115 0071 0402 0219 0451 0371 0266 0037
ALL	0041 0582 0351 0034 0035 0502 0136
MD12E	0584
SL6-1	0584
TW6328	0584

PHOCUS

Model No	Codes	Notes
ALL	1317 1336 0742	

PHOENIX

Model No	Codes	Notes
ALL	0348	
ALL	0244 0514 0100 0065 0297 0115 0616 0498 0191 0398 0584	

PHONOLA

Model No	Codes	Notes
ALL	0041	
ALL	0221 0584 0065 0244 0115 0040	

PILOT

Model No	Codes	Notes
ALL	0584 0065	

PIONEER

Model No	Codes	Notes
ALL	0707	
ALL	0137 0194 0451 0191 0065 0398 0371 0389 0514 0039 0198 0584 0315 0540	
ALL	0636 0788	V4 or Higher RCU Required
CUSD025	0636	V4 or Higher RCU Required
PDP434HDE	0194	
PDP435FDE	0194	
PDP435PE	0194	
PDP505XDE	0194	
SD25AV1	0636	V4 or Higher RCU Required
SD28AV1	0636	V4 or Higher RCU Required

PIONIER

Model No	Codes	Notes
ALL	0398 0514	

PLANTRON

Model No	Codes	Notes
ALL	0037 0065 0292 0584	

PLAYSONIC

Model No	Codes	Notes
ALL	0742 0743	V4 or Higher RCU Required
ALL	0245 0065 0367	
NR33B4TL5NX	0742	V4 or Higher RCU Required

PLUS

Model No	Codes	Notes
ALL	0799	

POLICOM

Model No	Codes	Notes
ALL	0137 0224 0226 0266 0389 0191 0098 0102 0115 0563	

POLYTRON

Model No	Codes	Notes
ALL	0310	

POPPY

Model No	Codes	Notes
ALL	0037	

PORTLAND

Model No	Codes	Notes
ALL	0652	V4 or Higher RCU Required
ALL	0402	
ALL	1937	V6 or Higher RCU Required
P14F5	0652	V4 ONLY RCU
R35F30	0652	V4 ONLY RCU

POWERPOINT

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required
ALL	0515 0065 0584	

PRANDONI-PRINCE

Model No	Codes	Notes
ALL	0275 0544 0103 0389 0391 0104	

PRECISION

Model No	Codes	Notes
ALL	0245	

PREMIER

Model No	Codes	Notes
ALL	0037 0292	

PRIMA

Model No	Codes	Notes
ALL	0060	
ALL	1297	
ALL	0037 0502 0292 0440	

PRINCESS

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

PRINSTON

Model No	Codes	Notes
ALL	1065	

PRINZ

Model No	Codes	Notes
ALL	0572 0100 0377 0222 0389	

PROFEX

Model No	Codes	Notes
ALL	0459 0191 0037 0389 0391 0104	

PROFI

Model No	Codes	Notes
ALL	0037	

PROFITRONIC

Model No	Codes	Notes
ALL	0065 0584	
ALL	0130	

PROLINE

Model No	Codes	Notes
1485R	0662	V4 or Higher RCU Required
1485T	0662	V4 or Higher RCU Required
20N1	0662	V4 or Higher RCU Required
20R1	0065	
288N1	0065	
28MIT	0065	
925983	0065	
97908	0065	
ALL	0662	V4 or Higher RCU Required
ALL	0065 0653 0349 0040 0100 0584 0649	
CTV28NIT	0065	
NV3200	0349	

NV332100	0065	
PT09DW1248	0662	V4 or Higher RCU Required
R40A01	0662	V4 or Higher RCU Required
R46G22	0662	V4 or Higher RCU Required
TBD1430	0065	
W28D1	0662	V4 or Higher RCU Required
ZON1	0349	

PROSONIC

Model No	Codes	Notes
930	0696	V4 or Higher RCU Required
ALL	1696	
ALL	0242 0244 0402 0065 0398 0399 0607 0584 0245	
ALL	0696 0742	V4 or Higher RCU Required
CTV3710DT	0696	V4 or Higher RCU Required

PROTECH

Model No	Codes	Notes
3731	0696	V4 or Higher RCU Required
3731T	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	0696	V4 or Higher RCU Required
ALL	0065 0245 0037 0584 0275 0377 0292 0365 0446 0459 0310 0191 0514	
ALL	1065 1696	
ALL	0130	
FA7040	0065	
PR28W57N	0595	

PROTON

Model No	Codes	Notes
ALL	0206	
ALL	0037 0672 0502	

PROVISION

Model No	Codes	Notes
ALL	1065	
ALL	0527 0065 0584	
ALL	0742	V4 or Higher RCU Required

PULSAR

Model No	Codes	Notes
ALL	0045	

PVISION

Model No	Codes	Notes
ALL	1219 0904 1246	

PYE

Model No	Codes	Notes
ALL	0041	
ALL	0584 0065 0040 0115 0402 0377 0440	
KS3457/OST	0065	
M1432-05	0584	
M2052/05X	0065	

PYMI

Model No	Codes	Notes
ALL	0037	

QINGDAO

Model No	Codes	Notes
ALL	0236 0254 0292 0440	

QUADRAL

Model No	Codes	Notes
ALL	0246	

QUASAR

Model No	Codes	Notes
ALL	0278	
ALL	0893	
ALL	0275 0678 0502 0037	

QUELLE

Model No	Codes	Notes
ALL	1065	
ALL	0039 0065 0098 0533 0102 0038 0132 0389 0137 0563 0572 0540 0377 0219 0064 0245 0275 0133 0584 0185 0223 0292 0318 0322 0374 0037	
ALL	0696	V4 or Higher RCU Required
ALL	1533 1038	V6 or Higher RCU Required
ALL	0040	
FK8186	0696	V4 or Higher RCU Required

QUESTA

Model No	Codes	Notes
ALL	0064 0060	

RADIALVA

Model No	Codes	Notes
ALL	0137 0246 0459 0191 0065 0584 0315 0365	

RADIOLA

Model No	Codes	Notes
----------	-------	-------

ALL	0040 0065 0584 0245	
-----	---------------------	--

RADIOMARELLI

Model No	Codes	Notes
----------	-------	-------

ALL	0115 0544 0229 0103 0275 0065 0584	
-----	------------------------------------	--

RADIOSHACK

Model No	Codes	Notes
----------	-------	-------

ALL	0206	
-----	------	--

ALL	0060 0182	
-----	-----------	--

ALL	0065 0584	
-----	-----------	--

RADIOTONE

Model No	Codes	Notes
----------	-------	-------

ALL	1065 1696	
-----	-----------	--

ALL	0398 0037 0065 0446 0292 0607 0584 0440	
-----	---	--

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

P37508	0696	V4 or Higher RCU Required
--------	------	---------------------------

P37508TEXT	0696	V4 or Higher RCU Required
------------	------	---------------------------

RANK

Model No	Codes	Notes
----------	-------	-------

ALL	0098	
-----	------	--

RANK ARENA

Model No	Codes	Notes
----------	-------	-------

ALL	0064 0185 0630	
-----	----------------	--

RBM

Model No	Codes	Notes
----------	-------	-------

ALL	0098 0117	
-----	-----------	--

RCA

Model No	Codes	Notes
ALL	0588 0653 0118 0363 0371	
ALL	0121 0646	

REALISTIC

Model No	Codes	Notes
ALL	0206	

RECOR

Model No	Codes	Notes
ALL	0065 0446 0584	

RECTILIGNE

Model No	Codes	Notes
ALL	0065 0584	

REDIFFUSION

Model No	Codes	Notes
ALL	0379 0229 0064 0576 0389 0374	

REDSTAR

Model No	Codes	Notes
ALL	0065 0584	

REFLEX

Model No	Codes	Notes
ALL	1065 1696	
ALL	0696	V4 or Higher RCU Required
ALL	0065 0584	

RELISYS

Model No	Codes	Notes
ALL	0893 0904 0905 0906 1234 1235 1243 1241 1242 1239 1237 1296 1326	

REOC

Model No	Codes	Notes
754	0742	V4 or Higher RCU Required
ABS7SZ206	0742	V4 or Higher RCU Required
ALL	0662 0742	V4 or Higher RCU Required
ALL	1937	V6 or Higher RCU Required
TT7	0742	V4 or Higher RCU Required

RERLEX

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
CTV3760	0696	V4 or Higher RCU Required
RC930	0696	V4 or Higher RCU Required

REVOX

Model No	Codes	Notes
ALL	0398 0065 0584	

REX

Model No	Codes	Notes
ALL	0234 0287	
ALL	0191 0275 0391 0292	

RFT

Model No	Codes	Notes
----------	-------	-------

ALL 0115 0398 0100 0292 0065 0584

RHAPSBODY

Model No	Codes	Notes
----------	-------	-------

ALL 0244

RICOH

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

RINEX

Model No	Codes	Notes
----------	-------	-------

ALL 0446

R-LINE

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584 0191

ROADSTAR

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0292 0246 0446 0065 0584 0310

ALL 0696 0742 V4 or Higher RCU Required

ALL 1065 1696 1217

ROBOTRON

Model No	Codes	Notes
----------	-------	-------

ALL 0115

RODEX

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

ROVER

Model No	Codes	Notes
----------	-------	-------

ALL	0905	
-----	------	--

ALL	0064	
-----	------	--

ROWA

Model No	Codes	Notes
----------	-------	-------

344	0726	V4 or Higher RCU Required
-----	------	---------------------------

514	0726	V4 or Higher RCU Required
-----	------	---------------------------

516	0726	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0726	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0584	
-----	------	--

ALL	0065 0292 0037 0245 0244 0615	
-----	-------------------------------	--

RTM344	0726	V4 or Higher RCU Required
--------	------	---------------------------

RTM514	0726	V4 or Higher RCU Required
--------	------	---------------------------

RTM516	0726	V4 or Higher RCU Required
--------	------	---------------------------

ROXY

Model No	Codes	Notes
----------	-------	-------

ALL	0476 0115	
-----	-----------	--

ROYAL LUX

Model No	Codes	Notes
----------	-------	-------

ALL	0398 0440 0363	
-----	----------------	--

RTF

Model No	Codes	Notes
----------	-------	-------

ALL	0115	
-----	------	--

RUKOPIR

Model No	Codes	Notes
----------	-------	-------

ALL	0584 0065	
-----	-----------	--

RUNCO

Model No	Codes	Notes
----------	-------	-------

ALL	0045	
-----	------	--

RUYI

Model No	Codes	Notes
----------	-------	-------

ALL	0255	
-----	------	--

SABA

Model No	Codes	Notes
----------	-------	-------

ALL	0115 0191 0137 0544 0371 0224 0363 0315 0103 0389 0226 0576 0653 0588 0499	
-----	---	--

ALL	0742	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0241 0427 0233	
-----	----------------	--

SACCS

Model No	Codes	Notes
----------	-------	-------

ALL	0266	
-----	------	--

SAGEM

Model No	Codes	Notes
----------	-------	-------

ALL	0310	
-----	------	--

ALL	0858 1341	V8 CODES ONLY
-----	-----------	---------------

ALL	0858 1341	
-----	-----------	--

SAIGE

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

SAIKOU

Model No	Codes	Notes
ALL	0285	

SAISHO

Model No	Codes	Notes
ALL	0061	
ALL	0039 0205 0263 0544 0037 0239 0292 0382 0459 0245 0103 0191 0572	

SAIVOD

Model No	Codes	Notes
ALL	1191 1065 1696	
ALL	1191 1065 1696	V8 CODES ONLY
ALL	0696	V4 or Higher RCU Required
ALL	0065 0584	

SAKAI

Model No	Codes	Notes
ALL	0191	

SAKURA

Model No	Codes	Notes
ALL	1231	V8 CODES ONLY
ALL	1231	

SALORA

Model No	Codes	Notes
14MF51	0649	V4 or Higher RCU Required
21K77	0391	

ALL	0649	V4 or Higher RCU Required
ALL	1265	V8 CODES ONLY
ALL	0391 0576 0191 0222 0377 0384 0387 0367 0389 0103 0318 0574 0392 0544 0236 0508	
ALL	1265	
RK100	0649	V4 or Higher RCU Required

SALSA

Model No	Codes	Notes
----------	-------	-------

ALL	0363	
-----	------	--

SAMBERS

Model No	Codes	Notes
----------	-------	-------

ALL	0241 0130	
-----	-----------	--

ALL	0104 0103 0544	
-----	----------------	--

SAMPO

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0064 0199 0502 0678	
-----	--------------------------	--

SAMSUNG

Model No	Codes	Notes
----------	-------	-------

00104A	0646	V4 or Higher RCU Required
--------	------	---------------------------

00104D	0646	V4 or Higher RCU Required
--------	------	---------------------------

00104J	0646	V4 or Higher RCU Required
--------	------	---------------------------

00116B	0646	V4 or Higher RCU Required
--------	------	---------------------------

00220A	0646	V4 or Higher RCU Required
--------	------	---------------------------

14MT34BU	0065	
----------	------	--

28C75V6	0646	V4 or Higher RCU Required
---------	------	---------------------------

29A5	0646	V4 or Higher RCU Required
------	------	---------------------------

29A6	0646	V4 or Higher RCU Required
------	------	---------------------------

29A7	0646	V4 or Higher RCU Required
------	------	---------------------------

32W6VN	0646	V4 or Higher RCU Required
3F1400050010	0672	V4 or Higher RCU Required
503IT	0584	
505018P	0088	
6888W	0646	V4 or Higher RCU Required
ALL	0206 0730 1277 1263 0710 0840 1340	
ALL	0642	V4 or Higher RCU Required
ALL	0206 0730 1277 1263 0710 0840 1340	V8 CODES ONLY
ALL	0646 0672	V4 or Higher RCU Required
ALL	0476 0060 0088 0502 0207 0254	
ALL	0065 0584 0615 0037 0245 0516 0292 0318 0236 0398 0244 0100 0118 0510 0547 0191 0653	
C120520BT	0065	
C121S20BT	0646	V4 or Higher RCU Required
C15052AT	0065	
C15332T	0065	
C15344NC	0646	V4 or Higher RCU Required
C15937AN	0615	
C1683CN	0646	V4 or Higher RCU Required
C16844N	0065	
C21ESSB	0502	
C221403N	0646	V4 or Higher RCU Required
CB20R1	0642	V4 or Higher RCU Required
CB20R1XXSA	0646	V4 or Higher RCU Required
CB21F5	0646	V4 or Higher RCU Required
CB21FS	0646	V4 or Higher RCU Required
CB21KDX	0646	V4 or Higher RCU Required
CB21KDXXSA	0646	V4 or Higher RCU Required
CB688TAB	0646	V4 or Higher RCU Required
CE21DN4	0065	
CI20S20BT	0615	V4 or Higher RCU Required
CI3373T	0065	
CI5013T	0065	
CI5322X	0065	
CI5937AN	0615	

CI68CN	0615	
CS2908WT	0646	V4 or Higher RCU Required
CS29A6NT	0646	V4 or Higher RCU Required
CS29D6S	0646	V4 or Higher RCU Required
CS29V5WT	0646	V4 or Higher RCU Required
CS722AWT	0672	V4 or Higher RCU Required
CS7277PF	0672	V4 or Higher RCU Required
CS765D	0672	V4 or Higher RCU Required
CS823AMF	0672	V4 or Higher RCU Required
CW21443N	0646	V4 or Higher RCU Required
CW21A113V	0646	V4 or Higher RCU Required
CW21A8VN	0646	V4 or Higher RCU Required
CW21C33NS	0646	V4 or Higher RCU Required
CW21C3W	0646	V4 or Higher RCU Required
CW21D83NS	0646	V4 or Higher RCU Required
CW25C339	0646	V4 or Higher RCU Required
CW25D83NS	0646	V4 or Higher RCU Required
CW28C33N	0646	V4 or Higher RCU Required
CW28C73N	0646	V4 or Higher RCU Required
CW28C75V	0646	V4 or Higher RCU Required
CW28C7DG	0646	V4 or Higher RCU Required
CW28C7NG	0646	V4 or Higher RCU Required
CW28C7VDG	0646	V4 or Higher RCU Required
CW28C7VNG	0646	V4 or Higher RCU Required
CW28C7VW	0646	V4 or Higher RCU Required
CW28C7VWG	0646	V4 or Higher RCU Required
CW28C7W	0646	V4 or Higher RCU Required
CW28C7WG	0646	V4 or Higher RCU Required
CW28C95V	0646	V4 or Higher RCU Required
CW28D83NS	0646	V4 or Higher RCU Required
CW29A8VHE	0646	V4 or Higher RCU Required
CW4468N	0672	V4 or Higher RCU Required
CW533CDG	0646	V4 or Higher RCU Required
CW533CNG	0646	V4 or Higher RCU Required

CW533CVDG	0646	V4 or Higher RCU Required
CW533CVNG	0646	V4 or Higher RCU Required
CW533CVW	0646	V4 or Higher RCU Required
CW533CVWG	0646	V4 or Higher RCU Required
CW533CW	0646	V4 or Higher RCU Required
CW533CWG	0646	V4 or Higher RCU Required
CW5344	0646	V4 or Higher RCU Required
CW5344DG	0646	V4 or Higher RCU Required
CW5344NG	0646	V4 or Higher RCU Required
CW5344VDG	0646	V4 or Higher RCU Required
CW5344VNG	0646	V4 or Higher RCU Required
CW5344VW	0646	V4 or Higher RCU Required
CW5344VWG	0646	V4 or Higher RCU Required
CW5344W	0646	V4 or Higher RCU Required
CW5344WG	0646	V4 or Higher RCU Required
CW593CDG	0646	V4 or Higher RCU Required
CW593CNG	0646	V4 or Higher RCU Required
CW593CVDG	0646	V4 or Higher RCU Required
CW593CVNG	0646	V4 or Higher RCU Required
CW593CVW	0646	V4 or Higher RCU Required
CW593CVWG	0646	V4 or Higher RCU Required
CW593CW	0646	V4 or Higher RCU Required
CW593CWG	0646	V4 or Higher RCU Required
CW5944DG	0646	V4 or Higher RCU Required
CW5944NG	0646	V4 or Higher RCU Required
CW5944VDG	0646	V4 or Higher RCU Required
CW5944VNG	0646	V4 or Higher RCU Required
CW5944VW	0646	V4 or Higher RCU Required
CW5944VWG	0646	V4 or Higher RCU Required
CW5944W	0646	V4 or Higher RCU Required
CW5944WG	0646	V4 or Higher RCU Required
CW6244W	0646	V4 or Higher RCU Required
CW683CDG	0646	V4 or Higher RCU Required
CW683CHG	0646	V4 or Higher RCU Required

CW683CVDG	0646	V4 or Higher RCU Required
CW683CVNG	0646	V4 or Higher RCU Required
CW683CVW	0646	V4 or Higher RCU Required
CW683CVWG	0646	V4 or Higher RCU Required
CW683CW	0646	V4 or Higher RCU Required
CW683CWG	0646	V4 or Higher RCU Required
CW6840DG	0646	V4 or Higher RCU Required
CW6840NG	0646	V4 or Higher RCU Required
CW6840VDG	0646	V4 or Higher RCU Required
CW6840VNG	0646	V4 or Higher RCU Required
CW6840VW	0646	V4 or Higher RCU Required
CW6840VWG	0646	V4 or Higher RCU Required
CW6840W	0646	V4 or Higher RCU Required
CW6840WG	0646	V4 or Higher RCU Required
CW6844DG	0646	V4 or Higher RCU Required
CW6844NG	0646	V4 or Higher RCU Required
CW6844VDG	0646	V4 or Higher RCU Required
CW6844VNG	0646	V4 or Higher RCU Required
CW6844VW	0646	V4 or Higher RCU Required
CW6844VWG	0646	V4 or Higher RCU Required
CW6844W	0646	V4 or Higher RCU Required
CW6844WG	0646	V4 or Higher RCU Required
CW68CNG	0646	V4 or Higher RCU Required
CW703CDG	0646	V4 or Higher RCU Required
CW703CNG	0646	V4 or Higher RCU Required
CW703CVDG	0646	V4 or Higher RCU Required
CW703CVNG	0646	V4 or Higher RCU Required
CW703CVW	0646	V4 or Higher RCU Required
CW703CVWG	0646	V4 or Higher RCU Required
CW703CW	0646	V4 or Higher RCU Required
CW703CWG	0646	V4 or Higher RCU Required
CW883NG	0646	V4 or Higher RCU Required
CWS1C33N	0646	V4 or Higher RCU Required
CZ21A083N	0646	V4 or Higher RCU Required

CZ21A8VN	0646	V4 or Higher RCU Required
CZ21D083N	0646	V4 or Higher RCU Required
CZ21D83N	0646	V4 or Higher RCU Required
CZ6844N	0646	V4 or Higher RCU Required
LE15E31S	0646	V4 or Higher RCU Required
LE20S51B	0646	V4 or Higher RCU Required
LE26R41BDX	0646	V4 or Higher RCU Required
LE26R51BD	0646	V4 or Higher RCU Required
LE32R41BD	0646	V4 or Higher RCU Required
LE32R51BD	0646	V4 or Higher RCU Required
LE36R41BD	0646	V4 or Higher RCU Required
LW15E23CB	0646	V4 or Higher RCU Required
LW17N23N	0646	V4 or Higher RCU Required
LW20M21C	0646	V4 or Higher RCU Required
LW22A13W	0646	V4 or Higher RCU Required
LW22A13WD	0646	V4 or Higher RCU Required
LW26A33W	0646	V4 or Higher RCU Required
LW26A33WX	0646	V4 or Higher RCU Required
LW32A23W	0646	V4 or Higher RCU Required
LW32A33WX	0646	V4 or Higher RCU Required
PLANO UW21J10VD	0646	V4 or Higher RCU Required
PS425SD	0646	V4 or Higher RCU Required
PS42D4S	0646	V4 or Higher RCU Required
PS42D4SXX	0646	V4 or Higher RCU Required
PS42P2SB	0646	V4 or Higher RCU Required
PS42P3S	0646	V4 or Higher RCU Required
PS42S5SD	0646	V4 or Higher RCU Required
PS42V4S	0646	V4 or Higher RCU Required
PSN4231	0672	V4 or Higher RCU Required
RMTV131B	0646	V4 or Higher RCU Required
SP42B5HF	0646	V4 or Higher RCU Required
SP42Q2HL	0646	V4 or Higher RCU Required
SP42W4HBX	0646	V4 or Higher RCU Required
SP42W4HL	0646	V4 or Higher RCU Required

SP42W4HP	0646	V4 or Higher RCU Required
SP42W4HPX	0646	V4 or Higher RCU Required
SP42W5HF	0646	V4 or Higher RCU Required
SP42W5HFX	0672	V4 or Higher RCU Required
SP42W5HFX	0646	V4 or Higher RCU Required
SP43W6H	0646	V4 or Higher RCU Required
SP43W6HL	0646	V4 or Higher RCU Required
SP43W6HLXPJTV	0646	V4 or Higher RCU Required
SP43W6HP	0672	V4 or Higher RCU Required
SP47W3HFX	0672	V4 or Higher RCU Required
SP50L7HX	0646	V4 or Higher RCU Required
SPM4388	0672	V4 or Higher RCU Required
SPM5288	0672	V4 or Higher RCU Required
TM57	0646	V4 or Higher RCU Required
TM59	0646	V4 or Higher RCU Required
TM59AA6450236	0646	V4 or Higher RCU Required
TV272	0672	V4 or Higher RCU Required
TV4881	0646	V4 or Higher RCU Required
TV6272	0672	V4 or Higher RCU Required
TV6330	0672	V4 or Higher RCU Required
TV686WP	0672	V4 or Higher RCU Required
TV8272	0672	V4 or Higher RCU Required
WF28V53N	0646	V4 or Higher RCU Required
WF28W6VNG	0646	V4 or Higher RCU Required
WF28W8VN	0646	V4 or Higher RCU Required
WS24W63N	0646	V4 or Higher RCU Required
WS24W63NS	0646	V4 or Higher RCU Required
WS24W64N	0646	V4 or Higher RCU Required
WS24W6DG	0646	V4 or Higher RCU Required
WS24W6NG	0646	V4 or Higher RCU Required
WS24W6VDG	0646	V4 or Higher RCU Required
WS24W6VN	0646	V4 or Higher RCU Required
WS24W6VNG	0646	V4 or Higher RCU Required
WS24W6VW	0646	V4 or Higher RCU Required

WS24W6VWG	0646	V4 or Higher RCU Required
WS24W6W	0646	V4 or Higher RCU Required
WS24W6WG	0646	V4 or Higher RCU Required
WS25W6VN	0646	V4 or Higher RCU Required
WS28A116	0646	V4 or Higher RCU Required
WS28A116DSXXEU	0646	V4 or Higher RCU Required
WS28A116T	0646	V4 or Higher RCU Required
WS28A116TGXXEU	0646	V4 or Higher RCU Required
WS28M064N	0646	V4 or Higher RCU Required
WS28M64N	0646	V4 or Higher RCU Required
WS28V53N	0646	V4 or Higher RCU Required
WS28V53NS	0646	V4 or Higher RCU Required
WS28W5VNS	0646	V4 or Higher RCU Required
WS28W63N	0646	V4 or Higher RCU Required
WS28W63NS8	0646	V4 or Higher RCU Required
WS28W6DG	0646	V4 or Higher RCU Required
WS28W6NG	0646	V4 or Higher RCU Required
WS28W6V9G	0088	
WS28W6VDG	0646	V4 or Higher RCU Required
WS28W6VN	0646	V4 or Higher RCU Required
WS28W6VNG	0646	V4 or Higher RCU Required
WS28W6VW	0646	V4 or Higher RCU Required
WS28W6VWG	0646	V4 or Higher RCU Required
WS28W6W	0646	V4 or Higher RCU Required
WS28W6WG	0646	V4 or Higher RCU Required
WS32A116	0646	V4 or Higher RCU Required
WS32A116DSX	0646	V4 or Higher RCU Required
WS32A116DSXXEU	0646	V4 or Higher RCU Required
WS32A116T	0646	V4 or Higher RCU Required
WS32M064	0672	V4 or Higher RCU Required
WS32M64V	0646	V4 or Higher RCU Required
WS32M064V	0646	V4 or Higher RCU Required
WS32V54NS	0646	V4 or Higher RCU Required
WS32W64VDG	0646	V4 or Higher RCU Required

WS32W66V	0646	V4 or Higher RCU Required
WS32W6DG	0646	V4 or Higher RCU Required
WS32W6NG	0646	V4 or Higher RCU Required
WS32W6VDG	0646	V4 or Higher RCU Required
WS32W6VNG	0646	V4 or Higher RCU Required
WS32W6VW	0646	V4 or Higher RCU Required
WS32W6VWG	0646	V4 or Higher RCU Required
WS32W6W	0646	V4 or Higher RCU Required
WS32W6WG	0646	V4 or Higher RCU Required
WS32W7NS	0646	V4 or Higher RCU Required
WS32Z306V	0646	V4 or Higher RCU Required
WS32Z306VB	0646	V4 or Higher RCU Required
WS32Z308P	0646	V4 or Higher RCU Required
WZ32W6VDG	0646	V4 or Higher RCU Required

SANDRA

Model No	Codes	Notes
ALL	0244 0245	

SANELA

Model No	Codes	Notes
ALL	0266	

SANJIAN

Model No	Codes	Notes
ALL	0292 0440	

SANSUI

Model No	Codes	Notes
ALL	0683 0916	V4 or Higher RCU Required
ALL	0065 0584 0399 0630	
RSS161	0683	V4 or Higher RCU Required

SV1402	0683	V4 or Higher RCU Required
SV2002	0683	V4 or Higher RCU Required
SV2102	0683	V4 or Higher RCU Required

SANTON

Model No	Codes	Notes
ALL	0037	

SANYO

Model No	Codes	Notes
026F0988	0236	
14MTZ	0236	
21DN2	0236	
21MTI	0236	
25BN1	0236	
28DN1	0236	
28DN2	0236	
29WN3	0236	
32FWN3	0236	
73SEN	0236	
ALL	1236	V6 or Higher RCU Required
ALL	0749 0763 0827 0921	
ALL	0732	V4 or Higher RCU Required
ALL	0749 0763 0827 0921	V8 CODES ONLY
ALL	0174 0246 0182 0241 0263 0440 0502 0536	
ALL	0236 0073 0100 0064 0185 0367 0039 0245 0572 0583 0037 0132 0244 0191 0398 0065 0136 0584 0514 0198	
C1614292	0236	
C21E57NB	0236	
C21EF55B	0236	
C21ES35B	0236	
C21W535B	0236	
C25DN4	0236	

C25EG77NB	0236
C25EG958	0236
C25EG98B	0236
C25EP57NB	0236
C28DN2	0236
C28EG95B	0236
C28EH25NB	0236
C28EH82F	0236
C28ER57NB	0236
C28WN1B	0236
CB6649	0236
CBP2152	0236
CBP2558	0236
CBP3012	0236
CE14MT4	0236
CE14MT4B	0236
CE21DN3	0236
CE21DN3B	0236
CE21DN4B	0236
CE21DN7/B	0236
CE21DNSB	0236
CE21MT3B	0236
CE21MT4	0236
CE21MT4B	0236
CE21MT4H/B	0236
CE23FWH4B	0236
CE24WN5B	0236
CE24WN6-B	0236
CE25DN4	0236
CE25DN5	0236
CE28DN4	0236
CE28DN8B	0236
CE28DN9B	0236
CE28FWH4B	0236

CE28FWN5B	0236
CE28FWN5BK	0236
CE28FWN6B	0236
CE28WN3	0236
CE28WN3B	0236
CE28WN4	0236
CE28WN4B	0236
CE28WN6B	0236
CE28WN7	0236
CE28WP5B	0236
CE31DN4B	0236
CE32FWH4/B	0236
CE32FWN3	0236
CE32FWN4BK	0236
CE32FWN6	0236
CE32WN4	0236
CE32WN5B	0236
CE32WN6B	0236
CE32WP3B	0236
CE32WP5B	0236
CPB2180A	0236

SANYUAN

Model No	Codes	Notes
ALL	0037	

SAVE

Model No	Codes	Notes
ALL	0065 0584	

SAVILLE

Model No	Codes	Notes
ALL	0051	

ALL	1936	V6 or Higher RCU Required
-----	------	---------------------------

SBR

Model No	Codes	Notes
----------	-------	-------

ALL	0040 0065 0584 0071 0221	
-----	--------------------------	--

SCHAUB LORENZ

Model No	Codes	Notes
----------	-------	-------

2102/2ST	0742	V4 or Higher RCU Required
2810/100	0742	V4 or Higher RCU Required
28BCTL2	0742	V4 or Higher RCU Required
ALL	1219	V8 CODES ONLY
ALL	0377 0389 0576 0634 0574 0514 0402	
ALL	1219	
ALL	0742	V4 or Higher RCU Required
SL21022ST	0742	V4 or Higher RCU Required
SL2810/100ST	0742	V4 or Higher RCU Required
SL3310	0742	V4 or Higher RCU Required

SCHNEIDER

Model No	Codes	Notes
----------	-------	-------

2803T	0065	
ALL	1165 1065 1696	V8 CODES ONLY
ALL	0065 0040 0245 0246 0275 0399 0389 0584 0572 0377 0371 0547 0191	
ALL	1936 1937	V6 or Higher RCU Required
ALL	1165 1065 1696	
ALL	0351 0041 0287 0422 0380 0364 0331	
ALL	0743	V4 or Higher RCU Required
ALL	0696 0742	V4 or Higher RCU Required
CINEMA281001	0742	V4 or Higher RCU Required
CINEMA2819	0742	V4 or Higher RCU Required
CINEMA3201	0065	

CINEMA3203	0742	V4 or Higher RCU Required
CT7951GB	0065	
NRSTV2804T	0742	V4 or Higher RCU Required
RC223	0696	V4 or Higher RCU Required
RC233	0696	V4 or Higher RCU Required
STV200-2T	0065	
STV2003-2	0065	
STV21200	0065	
STV21201	0742	V4 or Higher RCU Required
STV21201	0743	V4 or Higher RCU Required
STV2802T	0065	
STV2804	0742	V4 or Higher RCU Required
STV2804T	0742	V4 or Higher RCU Required
STV360	0696	V4 or Higher RCU Required
STV365	0696	V4 or Higher RCU Required
SVTV1451	1936	V6 or Higher RCU Required

SCOTLAND

Model No	Codes	Notes
ALL	0191	

SCOTT

Model No	Codes	Notes
ALL	1217 0206	
ALL	1217 0206	V8 CODES ONLY
ALL	0207	

SEARS

Model No	Codes	Notes
ALL	0206	V8 CODES ONLY
ALL	0206	
ALL	0199 0207	

SEAWAY

Model No	Codes	Notes
ALL	0652 0696	
ALL	0662	V4 or Higher RCU Required
R40A01	0652	V4 ONLY RCU
SWTV80	0652	V4 ONLY RCU

SEELVER

Model No	Codes	Notes
ALL	1065	V8 CODES ONLY
ALL	0584 0065	
ALL	1065	

SEG

Model No	Codes	Notes
1030	0696	V4 or Higher RCU Required
3798	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	1065 1465 1191 1696	
ALL	1065 1465 1191 1696	V8 CODES ONLY
ALL	1937	V6 or Higher RCU Required
ALL	0662 0696	V4 or Higher RCU Required
ALL	0065 0064 0245 0584 0292 0515 0037 0377 0191 0275 0390 0244 0104 0246	
CT1900	0696	V4 or Higher RCU Required
CT1901	0696	V4 or Higher RCU Required
CT2802S	0065	
CT2900	0696	V4 or Higher RCU Required
CT3212	0065	
CT7000800GB	0065	
CT7800	0696	V4 or Higher RCU Required
CT7951GB	0065	

DVT14F6FSD	0662	V4 or Higher RCU Required
MADRID	0696	V4 or Higher RCU Required
PREMIUM	0696	V4 or Higher RCU Required
R46F02	0662	V4 or Higher RCU Required
ROM	0696	V4 or Higher RCU Required

SEI

Model No	Codes	Notes
ALL	0115 0205 0544 0533 0572 0038 0191 0103 0377 0322 0065 0584	
ALL	1533 1038	V6 or Higher RCU Required

SEI-SINUDYNE

Model No	Codes	Notes
ALL	0322 0544 0533 0038 0572 0065 0584 0115	
ALL	1533 1038	V6 or Higher RCU Required

SELECO

Model No	Codes	Notes
ALL	0701	V8 CODES ONLY
ALL	0234 0287	
ALL	0701	
ALL	0191 0390 0391 0399 0064 0292 0374	

SENCORA

Model No	Codes	Notes
ALL	0037	

SENTRA

Model No	Codes	Notes
ALL	0037 0311 0063 0246 0304 0377	

SERINO

Model No	Codes	Notes
ALL	0244 1121	

SHANCHA

Model No	Codes	Notes
ALL	0292 0440	

SHANGHAI

Model No	Codes	Notes
ALL	0037 0236 0254 0292 0440	

SHAOFENG

Model No	Codes	Notes
ALL	0255	

SHARP

Model No	Codes	Notes
28-592	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28HW50CH	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28HW53H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28JF73H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28JF74H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28JW73H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
28LF92H,	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221

28LW92H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32JF73H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32JF74H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32JF92H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32JW73H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32LF92H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
32LW92H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
37DT25H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
51DS03H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
51DT25H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
51FS51H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
51GT25H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
59CSDAH	0065	
59DS03H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66AF/05H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66CS0TH	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66DS03H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66ES03H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66FW53H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66FWF/54H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66GF63H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221

66GS62H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
66SW53H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
76SWS3H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
ALL	1221	V6 or Higher RCU Required
ALL	0788	V4 or Higher RCU Required
ALL	0322 0185 0519 0681 0221 0544	
ALL	0846 0880 1421 1191	V8 CODES ONLY
ALL	0121 0064 0065 0081 0122 0037 0502 0678	
ALL	1121 0846 0880 1421 1191	
CV2133H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
CV2133HBK	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
CV2133IR	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
CV3730H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DB5903H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5103H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5105H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5107H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV51328	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5161H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5932H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV5940H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
DV594TH	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC13E1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221

LC13S1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC15E1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC15S1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC20E1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC20S1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC20SH1E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC22SV2E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC26GA3E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC26GA5E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC26P50E	0121	
LC30HV4E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC32GA3E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC32GA5E	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221
LC32P50E	0121	
S6FWS3H	0121	NOT A V6 RCU. IF A V6 RCU ENTER AS 1221

SHEN YING

Model No	Codes	Notes
ALL	0037 0207 0502	

SHENCAI

Model No	Codes	Notes
ALL	0037 0292 0440	

SHENG CHAI

Model No	Codes	Notes
ALL	0502 0037 0207	
SHENG CHIA		
Model No	Codes	Notes
ALL	0037 0207 0502	
SHENYANG		
Model No	Codes	Notes
ALL	0037 0292	
ALL	0724	V4 or Higher RCU Required
SHERWOOD		
Model No	Codes	Notes
ALL	0037	
SHINTOSHI		
Model No	Codes	Notes
ALL	0065 0584	
SHIVAKI		
Model No	Codes	Notes
ALL	0065 0584 0471 0402	
ALL	0206	V8 CODES ONLY
SHORAI		
Model No	Codes	Notes
ALL	0322 0207	
SHOW		

Model No	Codes	Notes
----------	-------	-------

ALL	0446 0037 0100	
-----	----------------	--

SIAREM

Model No	Codes	Notes
----------	-------	-------

ALL	0241 0191 0130 0335 0115 0103 0544	
-----	------------------------------------	--

SIEMENS

Model No	Codes	Notes
----------	-------	-------

ALL	0563 0582 0355 0356 0185 0065 0241 0174 0060 0219 0223 0329 0228 0584 0389	
-----	---	--

SIERRA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0040 0615	
-----	---------------------	--

SIESTA

Model No	Codes	Notes
----------	-------	-------

ALL	0398	
-----	------	--

SILVA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0244 0389	
-----	---------------------	--

SILVA SCHNEIDER

Model No	Codes	Notes
----------	-------	-------

ALL	1584	V6 or Higher RCU Required
-----	------	---------------------------

SILVER

Model No	Codes	Notes
----------	-------	-------

ALL	0389 0064 0207 0065 0584 0191	
ALL	0743	V4 or Higher RCU Required
CA2158	0207	
UTV9014XL	0743	V4 or Higher RCU Required

SILVERCREST

Model No	Codes	Notes
ALL	1065	V8 CODES ONLY
ALL	0065 0584	

SIM TWO MULTIMEDIA

Model No	Codes	Notes
ALL	1325	V8 CODES ONLY

SINGER

Model No	Codes	Notes
ALL	0037 0115 0065 0584 0275 0363 0191	

SINUDYNE

Model No	Codes	Notes
ALL	0389 0263 0038 0544 0191 0234 0065 0377 0115 0241 0130 0322 0205 0103 0572 0533 0035 0584	
ALL	1533 1038 1936	V6 or Higher RCU Required

SKANTIC

Model No	Codes	Notes
ALL	0384	

SKY

Model No	Codes	Notes
ALL	0908 0206	V8 CODES ONLY

ALL	0065 0310 0584	
ALL	0604 0662	V4 or Higher RCU Required
PDS4250	0662	V4 or Higher RCU Required
SCRT3202	0065	
SPDP3205	0604	
SPDP4202	0604	
UFKON824N48W300	0065	

SKYMASTER

Model No	Codes	Notes
----------	-------	-------

ALL	0133	
-----	------	--

SKYSONIC

Model No	Codes	Notes
----------	-------	-------

ALL	0724	V4 or Higher RCU Required
-----	------	---------------------------

SKYWORTH

Model No	Codes	Notes
----------	-------	-------

ALL	0724 0726	V4 or Higher RCU Required
-----	-----------	---------------------------

ALL	0065 0584 0037 0292	
-----	---------------------	--

SLIDING

Model No	Codes	Notes
----------	-------	-------

ALL	0893 0908 0828	V8 CODES ONLY
-----	----------------	---------------

SLX

Model No	Codes	Notes
----------	-------	-------

3745TSL	0696	V4 or Higher RCU Required
---------	------	---------------------------

930	0696	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0065	
-----	------	--

ALL	1696	V8 CODES ONLY
-----	------	---------------

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

T1T2 0065

SMARAGD

Model No Codes Notes

ALL 0515

SOEMTRON

Model No Codes Notes

ALL 0893 1326 V8 CODES ONLY

SOGERA

Model No Codes Notes

ALL 0348

SOLAVOX

Model No Codes Notes

ALL 0389 0060 0100 0191 0576 0379 0065 0584

SONAWA

Model No Codes Notes

ALL 0246

SONGBA

Model No Codes Notes

ALL 0037

SONIKO

Model No Codes Notes

ALL 0065 0584

SONITRON

Model No	Codes	Notes
----------	-------	-------

ALL	0236 0398 0367 0245	
-----	---------------------	--

SONIX

Model No	Codes	Notes
----------	-------	-------

ALL	NO CODES AVAILABLE	
-----	--------------------	--

SONNECLAIR

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584	
-----	-----------	--

SONOKO

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0065 0584 0292 0310 0245	
-----	-------------------------------	--

SONOLOR

Model No	Codes	Notes
----------	-------	-------

ALL	0191 0236 0533 0038 0576 0389 0310	
-----	------------------------------------	--

ALL	1533 1038	V6 or Higher RCU Required
-----	-----------	---------------------------

SONTEC

Model No	Codes	Notes
----------	-------	-------

ALL	0322 0065 0398 0584 0037	
-----	--------------------------	--

SONY

Model No	Codes	Notes
----------	-------	-------

24WIT	0038	
-------	------	--

ALL	0770 1779 0862	V8 CODES ONLY
-----	----------------	---------------

ALL	0533 0038 0039 0064 0102 0130 0505 0678 0381 0065 0584 0185	
-----	--	--

ALL	0679	V4 ONLY RCU
-----	------	-------------

ALL	1533 1679 1038	V6 or Higher RCU Required
FX60	0533	
FX642170	0533	
KD28/32EX	0533	
KD28DL10U	0533	
KD28DL11U	0533	
KD28DL1SU	0505	
KD28DX40U	0533	
KD28EXK	0533	
KD32DX150U	0533	
KD32DX40U	0533	
KD32EXK	0533	
KEP37XS1	0533	
KEPXS1	0533	
KF42SX300U	0533	
KF60SX300U	0533	
KLV30HR3	0533	
KLVL32MI	0679	V4 ONLY RCU
KP41DS1U	0679	V4 ONLY RCU
KP41S34	0679	V4 ONLY RCU
KPS4112U	0679	V4 ONLY RCU
KV14T1I	0533	
KV14T1U	0533	
KV2171U	0533	
KV217IU	0533	
KV21LS30U	0679	V4 ONLY RCU
KV24WX1U	0533	
KV2552U	0533	
KV25X5U	0533	
KV28CF70U	0533	
KV28CL10U	0533	
KV28CLI0U	0533	
KV28CS70U	0533	
KV28DS20	0679	V4 ONLY RCU

KV28DS60U	0533	
KV28DX30U	0679	V4 ONLY RCU
KV28FQ75U	0533	
KV28FS20U	0533	
KV28FX20U	0679	V4 ONLY RCU
KV28FX60B	0679	V4 ONLY RCU
KV28FX60U	0679	V4 ONLY RCU
KV28FX66U	0505	
KV28FX68U	0533	
KV28HX15U	0533	
KV28LF35U	0533	
KV28LS35U	0533	
KV28LS36U	0533	
KV28SK68U	0533	
KV28SX60U	0038	
KV2951D	0679	V4 ONLY RCU
KV2952U	0533	
KV2961D	0679	V4 ONLY RCU
KV29E1D	0679	V4 ONLY RCU
KV29F1U	0533	
KV29FX60U	0679	V4 ONLY RCU
KV29S2B	0679	V4 ONLY RCU
KV29X1U	0533	
KV29X2B	0679	V4 ONLY RCU
KV29X2D	0679	V4 ONLY RCU
KV29X5U	0533	
KV321S36U	0533	
KV32CS70U	0533	
KV32D560U	0533	
KV32DF20	0533	
KV32DS204	0679	V4 ONLY RCU
KV32DS209U	0679	V4 ONLY RCU
KV32DS60U	0533	
KV32FX60	0679	V4 ONLY RCU

KV32FX60B	0679	V4 ONLY RCU
KV32FX60U	0679	V4 ONLY RCU
KV32FX68U	0533	
KV32HX15U	0533	
KV32LS35U	0533	
KV32LS36U	0533	
KV32WS2	0533	
KV3431	0679	V4 ONLY RCU
KV36FS70	0679	V4 ONLY RCU
KVA2131B	0679	V4 ONLY RCU
KVA2531B	0679	V4 ONLY RCU
KVA2542U	0533	
KVA2931B	0679	V4 ONLY RCU
KVE2941D	0679	V4 ONLY RCU
KVHX15U	0533	
KVM2151U	0533	
KVS2941D	0679	V4 ONLY RCU
KVS2953B	0679	V4 ONLY RCU
KVS2953E	0679	V4 ONLY RCU
KVX21720	0533	
KVX2572U	0533	
KVX2582U	0533	
KVX2972U	0533	
KX28HX15U	0533	
RM831	0679	V4 ONLY RCU
RM887	0679	V4 ONLY RCU
RM888	0679	V4 ONLY RCU
RM891	0679	V4 ONLY RCU
RM892	0679	V4 ONLY RCU
RMTV222D	0679	V4 ONLY RCU
RMU303	0679	V4 ONLY RCU
RMU305	0679	V4 ONLY RCU
SLVF900UX	0679	V4 ONLY RCU
SLVF900VX	0679	V4 ONLY RCU

STRDE335	0679	V4 ONLY RCU
----------	------	-------------

SOUND & VISION

Model No	Codes	Notes
----------	-------	-------

ALL	0246 0402 0065 0584	
-----	---------------------	--

SOUNDESIGN

Model No	Codes	Notes
----------	-------	-------

ALL	0206	V8 CODES ONLY
-----	------	---------------

ALL	0207	
-----	------	--

SOUNDWAVE

Model No	Codes	Notes
----------	-------	-------

ALL	0446 0065 0348 0584	
-----	---------------------	--

ALL	0743	V4 or Higher RCU Required
-----	------	---------------------------

SOWA

Model No	Codes	Notes
----------	-------	-------

ALL	0502 0254 0064	
-----	----------------	--

SPECTRA

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

SQUAREVIEW

Model No	Codes	Notes
----------	-------	-------

ALL	0199	
-----	------	--

SSANGYONG

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0060

STAKSONIC

Model No	Codes	Notes
----------	-------	-------

ALL 0037

STANDARD

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0245 0246 0402 0065 0348 0584

ALL 1065 V8 CODES ONLY

STARLITE

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0037 0191 0584 0292 0440

STENWAY

Model No	Codes	Notes
----------	-------	-------

ALL 0310 0246

STERN

Model No	Codes	Notes
----------	-------	-------

ALL 0191 0391 0292

STEVISION

Model No	Codes	Notes
----------	-------	-------

ALL 1584 V6 or Higher RCU Required

STRATO

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0037 0292 0584

STRONG

Model No	Codes	Notes
ALL	1191 1177 1065 0902	V8 CODES ONLY
ALL	0065 0584	

STUDIO EXPERIENCE

Model No	Codes	Notes
ALL	0871	

STYLANDIA

Model No	Codes	Notes
ALL	0245	

SUNIC LINE

Model No	Codes	Notes
ALL	0065 0584	

SUNKAI

Model No	Codes	Notes
ALL	0893	V8 CODES ONLY
ALL	0349 0322 0383 0246 0263 0065 0584 0515 0559	

SUNSTAR

Model No	Codes	Notes
ALL	0037 0065 0399 0584 0607 0292	

SUNWOOD

Model No	Codes	Notes
ALL	0065 0584 0037	

SUPERLA

Model No	Codes	Notes
ALL	0103 0544 0244 0245	

SUPERSONIC

Model No	Codes	Notes
ALL	0236 0584 0292	
ALL	0726	V4 or Higher RCU Required

SUPERTECH

Model No	Codes	Notes
ALL	0584 0065 0244 0037 0246	

SUPERTON

Model No	Codes	Notes
ALL	0103 0459	

SUPRA

Model No	Codes	Notes
ALL	0402 0037	
ALL	0206	V8 CODES ONLY

SUSUMU

Model No	Codes	Notes
ALL	0502 0297 0363 0246 0315	

SUTRON

Model No	Codes	Notes
ALL	0037	

SVA

Model No	Codes	Notes
ALL	0615	

SWISSLINE

Model No	Codes	Notes
ALL	0275	

SWISSTEC

Model No	Codes	Notes
ALL	NO CODES AVAILABLE	

SYDNEY

Model No	Codes	Notes
ALL	0245 0244	

SYLVANIA

Model No	Codes	Notes
ALL	0199	

SYMPHONIC

Model No	Codes	Notes
ALL	0199	
ALL	1932	V6 or Higher RCU Required

SYNCO

Model No	Codes	Notes
ALL	0064 0502	

SYSLINE

Model No	Codes	Notes
ALL	0065 0584	
SYTONG		

Model No	Codes	Notes
ALL	0244	
T+A		

Model No	Codes	Notes
ALL	0475	
TACICO		

Model No	Codes	Notes
ALL	0502 0207 0311 0037	
TACTUS		

Model No	Codes	Notes
ALL	0300	
TAI YI		

Model No	Codes	Notes
ALL	0037	
TAISHAN		

Model No	Codes	Notes
ALL	0037 0402	
TANDBERG		

Model No	Codes	Notes
ALL	0389 0137 0365 0395 0390 0224 0191	

TANDY

Model No	Codes	Notes
ALL	0246 0100 0245 0191 0304 0275 0121	

TARGA

Model No	Codes	Notes
ALL	0730	V8 CODES ONLY

TASHIKO

Model No	Codes	Notes
ALL	0071 0174 0244 0060 0387 0245 0285 0616 0198 0064 0191 0678 0391	

TATUNG

Model No	Codes	Notes
ALL	1584 1084 1936	V6 or Higher RCU Required
ALL	0065 0100 0544 0300 0277 0245 0272 0077 0039 0103 0037 0064 0584 0502 0657 0581 0084	
ALL	0649	V4 or Higher RCU Required
RC300	0084	
RK100	0649	V4 or Higher RCU Required
T14RK70	0649	V4 or Higher RCU Required
T20TK70	0649	V4 or Higher RCU Required
T21NT92	0065	
T21TD61	0065	
T21TK70	0649	V4 or Higher RCU Required
T289430	0065	
T2896430	0065	
T20TD51	0065	
TUNOA51	0065	
TUV9731	0100	
TYN9B01P	0065	

TCL

Model No	Codes	Notes
ALL	0440	
ALL	0726	V4 or Higher RCU Required

TCM

Model No	Codes	Notes
10502	0742	V4 or Higher RCU Required
ALL	0742	V4 or Higher RCU Required
ALL	1317	V8 CODES ONLY

TEAC

Model No	Codes	Notes
930	0696	V4 or Higher RCU Required
ALL	1465 1065 0206 0749 0783 1696 1752 1177 1783 1231	V8 CODES ONLY
ALL	0652 0662 0696 0726 0742	V4 or Higher RCU Required
ALL	1937	V6 or Higher RCU Required
ALL	0199 0292 0540 0065 0483 0037 0440 0310 0446 0584 0572 0245 0377 0459 0198	
CTDV512	0726	V4 or Higher RCU Required
CTM342H	0726	V4 or Higher RCU Required
CTM4122H	0726	V4 or Higher RCU Required
CTM4828H	0726	V4 or Higher RCU Required
CTM5122H	0726	V4 or Higher RCU Required
CTM5150H	0726	V4 or Higher RCU Required
EU2880	0742	V4 or Higher RCU Required
EU3280	0742	V4 or Higher RCU Required
EU34T	0696	V4 or Higher RCU Required
EU68F	0742	V4 or Higher RCU Required
M5122H	0726	V4 or Higher RCU Required
MV1421	0652	V4 ONLY RCU
MV1422	0652	V4 ONLY RCU

MV4822	0652	V4 ONLY RCU
RC309	0726	V4 or Higher RCU Required
RC35	0652	V4 ONLY RCU
RC747	0726	V4 or Higher RCU Required
RC757	0652	V4 ONLY RCU
RC772	0696	V4 or Higher RCU Required
UE34T	0696	V4 or Higher RCU Required

TEC

Model No	Codes	Notes
ALL	0499 0037 0245 0275 0502 0304 0363 0365 0065 0584 0389 0191	

TECH LINE

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
ALL	0065 0584	
FFS36	0696	V4 or Higher RCU Required

TECH LUX

Model No	Codes	Notes
ALL	1217	V8 CODES ONLY

TECHICA

Model No	Codes	Notes
ALL	0246	

TECHNICS

Model No	Codes	Notes
ALL	0278 0678	

TECHNISAT

Model No	Codes	Notes
7000	0683	V4 or Higher RCU Required
ALL	1295	V8 CODES ONLY
ALL	0065 0584 0191	
ALL	0683	V4 or Higher RCU Required
KINOSAT	0683	V4 or Higher RCU Required
KINOSAT16:9	0683	V4 or Higher RCU Required
Kinostar	0683	V4 or Higher RCU Required
TECHNISTAR4:3	0683	V4 or Higher RCU Required

TECHNISSON

Model No	Codes	Notes
ALL	0742	V4 or Higher RCU Required
ALL	1317	V8 CODES ONLY

TECHNOL ACE

Model No	Codes	Notes
ALL	0207	

TECHNOSONIC

Model No	Codes	Notes
ALL	0065 0584	
DTR110	0065	
WCT2816T	0065	

TECHWOOD

Model No	Codes	Notes
ALL	1191	V8 CODES ONLY
ALL	0065	
TWD28RF1	0065	

TECNIMAGEN

Model No	Codes	Notes
----------	-------	-------

ALL	0584	
-----	------	--

TECO

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0064 0246 0292 0502 0681	
-----	-------------------------------	--

ALL	1068	V8 CODES ONLY
-----	------	---------------

TEDELEX

Model No	Codes	Notes
----------	-------	-------

ALL	0245 0446 0634 0037 0236 0615 0065 0312 0584 0459	
-----	--	--

ALL	0726	V4 or Higher RCU Required
-----	------	---------------------------

TEIRON

Model No	Codes	Notes
----------	-------	-------

ALL	0037	
-----	------	--

TEKNIKA

Model No	Codes	Notes
----------	-------	-------

ALL	0207	
-----	------	--

TELE SYSTEM

Model No	Codes	Notes
----------	-------	-------

ALL	0904	V8 CODES ONLY
-----	------	---------------

TELEAVIA

Model No	Codes	Notes
----------	-------	-------

ALL	0137 0371 0315 0224	
-----	---------------------	--

TELECOR

Model No	Codes	Notes
ALL	0065 0584 0191 0246 0245 0312	
TELEFUNKEN		
Model No	Codes	Notes
ALL	0726 0742	V4 or Higher RCU Required
ALL	0730 0137	V8 CODES ONLY
ALL	1584	V6 or Higher RCU Required
ALL	0137 0363 0101 0371 0129 0065 0315 0499 0334 0427 0224 0505 0033 0514 0112 0280 0290 0102 0653 0588 0615 0584	
TTV210	0726	V4 or Higher RCU Required
TTV240	0726	V4 or Higher RCU Required

TELEFUSION

Model No	Codes	Notes
ALL	0065 0584	

TELEGAZI

Model No	Codes	Notes
ALL	0065 0191 0246 0292 0312 0584	

TELEMEISTER

Model No	Codes	Notes
ALL	0348 0065 0584	

TELESONIC

Model No	Codes	Notes
ALL	0065 0584	

TELESTAR

Model No	Codes	Notes
ALL	0065 0037 0584 0607 0440	

TELETECH

Model No	Codes	Notes
1030	0696	V4 or Higher RCU Required
ALL	1065 1696	V8 CODES ONLY
ALL	0065 0037 0365 0275 0584	
ALL	0696	V4 or Higher RCU Required
CT360	0696	V4 or Higher RCU Required
CT361	0696	V4 or Higher RCU Required

TELETON

Model No	Codes	Notes
ALL	0287 0245 0234 0064 0191 0377 0391	

TELEVIDEON

Model No	Codes	Notes
ALL	0244 0191 0348	

TELEVIEW

Model No	Codes	Notes
ALL	0065 0584	

TEMCO

Model No	Codes	Notes
ALL	0322	

TEMPEST

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0065 0584 0292

TENNESSEE

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

TENSAI

Model No	Codes	Notes
----------	-------	-------

ALL 0275 0037 0132 0405 0245 0322 0133 0345 0348
0402 0246 0399 0065 0584 0191

ALL 0743 V4 or Higher RCU Required

ALL 1065 V8 CODES ONLY

TCT1410PX 0743 V4 or Higher RCU Required

TENSON

Model No	Codes	Notes
----------	-------	-------

ALL 0037 0348

TERA

Model No	Codes	Notes
----------	-------	-------

ALL 0502 0311

TESLA

Model No	Codes	Notes
----------	-------	-------

ALL 0065

TEVION

Model No	Codes	Notes
----------	-------	-------

1530 0696 V4 or Higher RCU Required

3731VT 0696 V4 or Higher RCU Required

ALL 1287 1326 1584 1165 1065 1696 1276 1317 V8 CODES ONLY

ALL	0696 0742	V4 or Higher RCU Required
ALL	0065 0547 0584	
MD3731VT	0696	V4 or Higher RCU Required
TBCTV2800	0742	V4 or Higher RCU Required
TFS28WD	0065	
TV66SIL	0065	

TEXET

Model No	Codes	Notes
----------	-------	-------

ALL	0245 0402 0037 0244 0246	
-----	--------------------------	--

THOMAS

Model No	Codes	Notes
----------	-------	-------

ALL	1932	V6 or Higher RCU Required
-----	------	---------------------------

THOMSON

Model No	Codes	Notes
----------	-------	-------

21DM183	0653	NOT A V4 RCU
21DS73H	0363	
21MG17UG	0653	NOT A V4 RCU
21MS20U	0363	
24W725US	0653	NOT A V4 RCU
24WK24U	0653	
24WK25UG	0653	NOT A V4 RCU
25DG17UG	0653	NOT A V4 RCU
27LCD8038	0653	NOT A V4 RCU
27WH101	0653	
28DG17UG	0653	NOT A V4 RCU
28WF201G	0653	NOT A V4 RCU
28WF401	0653	NOT A V4 RCU
28WF45E	0653	NOT A V4 RCU
28WF45UG	0653	NOT A V4 RCU
28WH101	0653	

28WH403	0653	NOT A V4 RCU
28WH403S	0653	NOT A V4 RCU
28WK24U	0653	NOT A V4 RCU
28WM101	0653	NOT A V4 RCU
28WN22E	0653	NOT A V4 RCU
28WR23UG	0653	NOT A V4 RCU
28WR25UG	0653	NOT A V4 RCU
28WS22U	0653	NOT A V4 RCU
28WS23U	0653	NOT A V4 RCU
28WS401G	0625	
28WS45U	0625	
28WX411S	0653	NOT A V4 RCU
28WZ413S	0653	NOT A V4 RCU
32UG	0653	NOT A V4 RCU
32WF25UG	0653	NOT A V4 RCU
32WF401G	0653	NOT A V4 RCU
32WF45U	0653	NOT A V4 RCU
32WF64EB	0625	
32WK65U	0653	NOT A V4 RCU
32WR25UG	0653	NOT A V4 RCU
32WT45US	0653	NOT A V4 RCU
ALL	0363 0653 0137 0224 0371 0065 0377 0233 0427 0361 0499 0315 0226 0588 0635 0625 0584	
ECT10	0653	NOT A V4 RCU

THORN

Model No	Codes	Notes
ALL	1533 1038	V6 or Higher RCU Required
ALL	0101 0221 0220 0218 0527 0065 0521 0402 0540 0063 0100 0132 0266 0533 0563 0397 0112 0387 0300 0102 0363 0581 0033 0136 0137 0253 0371 0389 0038 0584 0039 0040 0064 0071 0073 0098 0129 0384	
C51T	0402	
CR5122T	0527	
CT22T	0218	

CT5122T	0402
CT512T	0218
CT514TN	0527
P1480R	0402

THORN FERGUSON

Model No	Codes	Notes
ALL	0132 0136 0371 0137 0218 0220 0266 0221 0389 0363 0527 0101 0063	

TINY

Model No	Codes	Notes
ALL	1224 1297	V8 CODES ONLY

TINY DIGITAL

Model No	Codes	Notes
ALL	0688	V4 or Higher RCU Required

TMK

Model No	Codes	Notes
ALL	0205	
ALL	0206	

TNCI

Model No	Codes	Notes
ALL	0045	

TOBISHI

Model No	Codes	Notes
ALL	0246	

TOBO

Model No	Codes	Notes
ALL	0037 0292 0440	

TOKAI

Model No	Codes	Notes
ALL	1065 1696	V8 CODES ONLY
ALL	0100 0065 0584 0365 0191 0245 0402 0037	
ALL	0696	V4 or Higher RCU Required

TOKAIDO

Model No	Codes	Notes
ALL	1065	V8 CODES ONLY

TOKYO

Model No	Codes	Notes
ALL	0244 0063 0476	

TOMASHI

Model No	Codes	Notes
ALL	0310 0246	

TONGGUANG

Model No	Codes	Notes
ALL	0292 0440	

TONGTEL

Model No	Codes	Notes
ALL	0615	

TOPLINE

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
ALL	1065	V8 CODES ONLY

TOSHIBA

Model No	Codes	Notes
14N21B2	0536	
14T01B	0746	V4 or Higher RCU Required
156T9B	0536	
175T9B	0536	
17WL46B	0536	
2101TB	0581	
2132DB	0536	
213T4B	0536	
2141TB	0581	
2151TB	0536	
2163DB	0536	
2173DB	0536	
2181TB	0536	
2197DB	0536	
21S04BG	0536	
21T01B	0746	V4 or Higher RCU Required
238DB	0536	
23ZP38B	0536	
24Z33B	0536	
25001TB7	0536	
2500TB	0536	
2505	0536	
2512DB	0536	
2527DB	0536	
2535DB	0536	

2539DB	0536
2545DB	0536
2550TB	0536
2552DB	0536
2563DB	0536
256T9B	0536
2573DB	0536
2573DB	0581
2577DB	0536
25DG17UG	0536
27WL46	0536
27WL46B	0536
27WL56P	0536
2805DB	0536
2812DB	0536
28207B	0536
2835DB	0536
2855DB	0536
2857DB	0536
285T8B	0536
2873DB	0536
2877DB	0536
2879DB	0536
2893DB	0536
28N03B	0536
28N33B	0536
28TZ29B	0581
28W23B	0536
28W8DB	0536
28W8DBA	0536
28W93B	0536
28WD	0536
28Z07B	0581
28Z13B	0536

28Z23B	0536
28Z27B2	0536
28ZH37B	0536
2939DB	0536
2987DB	0536
322D09B	0536
32317B	0536
32DB	0536
32M8DB	0536
32M9DB3	0536
32NW7DB	0536
32NWDB	0536
32W33B	0536
32W8DB	0536
32WD98B	0536
32WIS	0536
32WL56	0536
32Z13B	0536
32Z17B	0536
32Z47	0536
32Z47B	0536
32ZD26P	0581
32ZD98B	0536
32ZD98G	0536
32ZP18P	0536
32ZP38	0581
3327DB	0536
3339DB	0536
3357DB	0536
3377DB	0536
337BB	0536
3387DB	0536
36/21P	0536
360P18P	0581

36ZD26P	0536	
36ZP18P	0581	
36ZP18Q	0581	
36ZP38B	0536	
36ZP45	0536	
36ZP48	0536	
3787DB	0536	
37WL56	0536	
40PW03B	0536	
40WH08B	0536	
42PW33P	0536	
42WH18B	0536	
42WH46	0536	
42WT29	0536	
439J936	0536	
43VJ13P	0581	
46WH08B	0536	
50WT29B	0536	
573DB	0536	
61PH18Q	0536	
82Z27B	0536	
82ZD16B	0536	
ALL	1936	V6 or Higher RCU Required
ALL	0646 0672 0726 0742 0746	V4 or Higher RCU Required
ALL	1536 1317 0064 1973 0764 1192 1191	V8 CODES ONLY
ALL	0536 0063 0271 0098 0117 0232 0530 0581 0130 0473 0088 0182 0064 0216 0253 0037 0255 0269 0292 0245 0440 0137 0223 0219 0678 0065 0508	
CT815	0746	V4 or Higher RCU Required
CT81500082B	0746	V4 or Higher RCU Required
CT824	0746	V4 or Higher RCU Required
CT832	0746	V4 or Higher RCU Required
CT90040	0508	
CT9689	0536	
MV40PWA	0536	

T1510T8	0536	
TVD213B	0726	V4 or Higher RCU Required
VTV1400	0536	

TOSUMI

Model No	Codes	Notes
----------	-------	-------

ALL	NO CODES AVAILABLE	
-----	--------------------	--

TOWADA

Model No	Codes	Notes
----------	-------	-------

ALL	0377 0130 0245	
-----	----------------	--

TOYODA

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0399 0304 0521 0292	
-----	--------------------------	--

TRAKTON

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0292 0245	
-----	----------------	--

TRANS CONTIN

Model No	Codes	Notes
----------	-------	-------

ALL	0696	V4 or Higher RCU Required
-----	------	---------------------------

TRANS CONTINENS

Model No	Codes	Notes
----------	-------	-------

ALL	0245 0065 0335 0584 0514	
-----	--------------------------	--

ALL	1065 1696	V8 CODES ONLY
-----	-----------	---------------

TRANS CONTINENS

Model No	Codes	Notes
MM3742	0696	V4 or Higher RCU Required
TR3610/2	0696	V4 or Higher RCU Required

TRANS-CONTINENTS

Model No	Codes	Notes
ALL		
ALL	0893	V8 CODES ONLY
ALL	0649	

TRANSONIC

Model No	Codes	Notes
ALL	0065 0584 0615 0540 0292 0446 0037	
ALL	0726	V4 or Higher RCU Required
CTV813	0726	V4 or Higher RCU Required
GT813B	0726	V4 or Higher RCU Required

TRANSTEC

Model No	Codes	Notes
ALL	0244	

TRIAD

Model No	Codes	Notes
ALL	0065 0584 0246	

TRICAL

Model No	Codes	Notes
ALL	0185	

TRIDENT

Model No	Codes	Notes
----------	-------	-------

ALL	0103 0544 0245	
-----	----------------	--

TRISTAR

Model No	Codes	Notes
----------	-------	-------

ALL	0292 0246 0221	
-----	----------------	--

TRIUMPH

Model No	Codes	Notes
----------	-------	-------

ALL	0584 0232 0205 0271 0065 0374 0544 0103	
-----	---	--

TSOSCHI

Model No	Codes	Notes
----------	-------	-------

ALL	0310	
-----	------	--

TUNTEX

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0502 0311	
-----	----------------	--

TVTEXT 95

Model No	Codes	Notes
----------	-------	-------

ALL	0584	
-----	------	--

UHER

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0398 0234 0402 0348 0287 0514 0104 0331 0446 0508	
-----	--	--

ULTRA

Model No	Codes	Notes
----------	-------	-------

ALL 0220

ULTRAVOX

Model No	Codes	Notes
----------	-------	-------

ALL 0115 0402 0275 0244 0191 0065 0584 0379

UNIC LINE

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584 0501 0377

UNITED

Model No	Codes	Notes
----------	-------	-------

ALL 1936 V6 or Higher RCU Required

ALL 0742 0743 V4 or Higher RCU Required

ALL 0065 0584

ALL 1065 0615 V8 CODES ONLY

APS610206C3 0742 V4 or Higher RCU Required

NRUTV2020X 0742 V4 or Higher RCU Required

UTV1028XNS 0742 V4 or Higher RCU Required

UTV2020X 0742 V4 or Higher RCU Required

UTV8014X 0743 V4 or Higher RCU Required

UTV9020L 0743 V4 or Higher RCU Required

UNIVERSAL

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

UNIVERSUM

Model No	Codes	Notes
----------	-------	-------

930 0696 V4 or Higher RCU Required

ALL 1065 1265 1465 1696 1191 V8 CODES ONLY

ALL 1533 1038 V6 or Higher RCU Required

ALL	0696	V4 or Higher RCU Required
	0065 0374 0102 0133 0132 0563 0223 0292 0398 0501 0389 0502 0275 0508 0446 0039 0540 0322	
ALL	0064 0185 0098 0191 0584 0516 0318 0533 0038 0104 0572 0377 0245 0137 0390 0365 0205 0037 0198 0659	
FK8185	0696	V4 or Higher RCU Required
FK8186	0696	V4 or Higher RCU Required
FK8190	0696	V4 or Higher RCU Required

UNIVOX

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0584 0115 0365 0266 0191	
-----	-------------------------------	--

UTAX

Model No	Codes	Notes
----------	-------	-------

ALL	0191	
-----	------	--

VESTEL

Model No	Codes	Notes
----------	-------	-------

3743T	0696	V4 or Higher RCU Required
930	0696	V4 or Higher RCU Required
ALL	0065 0245 0191 0584	
ALL	0696	V4 or Higher RCU Required
ALL	1065 1696 1191	V8 CODES ONLY
RC930	0696	V4 or Higher RCU Required

VEXA

Model No	Codes	Notes
----------	-------	-------

ALL	0065 0037 0584	
-----	----------------	--

VIBRANT

Model No	Codes	Notes
----------	-------	-------

ALL 0300

VICTOR

Model No Codes Notes

ALL 0681 0064 0678

VIDEOCON

Model No Codes Notes

ALL 0536

VIDEOLOGIC

Model No Codes Notes

ALL 0246 0244

VIDEOLOGIQUE

Model No Codes Notes

ALL 0244 0246 0245

VIDEOSAT

Model No Codes Notes

ALL 0275

VIDEOSEVEN

Model No Codes Notes

ALL 1783 0206 0908 1245 V8 CODES ONLY

VIDEOSYSTEM

Model No Codes Notes

ALL 0065 0584

VIDEOTECHNIC

Model No	Codes	Notes
----------	-------	-------

ALL	0244 0245 0402	
-----	----------------	--

VIDEOTON

Model No	Codes	Notes
----------	-------	-------

ALL	0459 0384 0191	
-----	----------------	--

VIDIKRON

Model No	Codes	Notes
----------	-------	-------

ALL	0130	
-----	------	--

ALL	0701 0643 0763	V8 CODES ONLY
-----	----------------	---------------

VIDTECH

Model No	Codes	Notes
----------	-------	-------

ALL	0064	
-----	------	--

VIEWPIA

Model No	Codes	Notes
----------	-------	-------

ALL	0904	V8 CODES ONLY
-----	------	---------------

VIPER

Model No	Codes	Notes
----------	-------	-------

ALL	0365	
-----	------	--

VISIOLA

Model No	Codes	Notes
----------	-------	-------

ALL	0244	
-----	------	--

VISION

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0348 0292 0584 0502 0245 0516

VISOREX

Model No	Codes	Notes
----------	-------	-------

ALL 0460

VISTAR

Model No	Codes	Notes
----------	-------	-------

ALL 0389 0304 0234

VORTEC

Model No	Codes	Notes
----------	-------	-------

ALL 0065 0584

VOXSON

Model No	Codes	Notes
----------	-------	-------

ALL 0446 0115 0065 0104 0391 0191 0584

ALL 0206 V8 CODES ONLY

WALLIS

Model No	Codes	Notes
----------	-------	-------

ALL 0820 V8 CODES ONLY

WALTHAM

Model No	Codes	Notes
----------	-------	-------

ALL 0696 V4 or Higher RCU Required

ALL 1065 1696 V8 CODES ONLY

ALL 0304 0315 0384 0065 0446 0245 0584 0137 0459

CT3759 0696 V4 or Higher RCU Required

WARDS

Model No	Codes	Notes
ALL	0207	
WARUMAIA		
Model No	Codes	Notes
ALL	0402	
WATSON		
Model No	Codes	Notes
930	0696	V4 or Higher RCU Required
ALL	0065 0348 0584 0191 0246 0607 0547 0037	
ALL	0696	V4 or Higher RCU Required
ALL	1065 1276 1465 1696	V8 CODES ONLY
ALL	1936	V6 or Higher RCU Required
FA2801TS	0065	
FA3201PS	0348	
FA3619	0696	V4 or Higher RCU Required
FA3629	0696	V4 or Higher RCU Required
FA5433TS	0584	
FA7039	0065	
FA7040	0065	

WATT RADIO

Model No	Codes	Notes
ALL	0241 0191 0130 0377 0244 0572	
WEGA		
Model No	Codes	Notes
ALL	0115 0065 0241 0064 0584	

WEGAVOX

Model No	Codes	Notes
ALL	0037 0065 0584	
WEIPEI		
Model No	Codes	Notes
ALL	0037	
WELLTECH		
Model No	Codes	Notes
40737	0742	V4 or Higher RCU Required
ALL	0742	V4 or Higher RCU Required
WELTBlick		
Model No	Codes	Notes
ALL	0245	V8 CODES ONLY
ALL	0348 0065 0584 0265	
WELTTECH		
Model No	Codes	Notes
ALL	0312	
WESTON		
Model No	Codes	Notes
ALL	0065 0584	
WHARFEDALE		
Model No	Codes	Notes
089	0065	
32P	0065	
350STB	0065	

550	0065	
550S	0065	
890	0584	
ALL	0699 0743	V4 or Higher RCU Required
ALL	0065 0547 0584	
ALL	1265	V8 CODES ONLY
ALL	1584	V6 or Higher RCU Required
CTV2185RF	0065	
M2163	0743	V4 or Higher RCU Required
RC514	0699	V4 or Higher RCU Required
T2811WS	0584	

WHIP

Model No	Codes	Notes
ALL	2015	V8 CODES ONLY

WHITE WESTINGHOUSE

Model No	Codes	Notes
ALL	0348 0365 0065 0244 0584	
ALL	0652	V4 or Higher RCU Required
ALL	1937	V6 or Higher RCU Required
WVT11311	0652	V4 ONLY RCU
WVT11911	0652	V4 ONLY RCU

WINDSOR

Model No	Codes	Notes
ALL	0696	V4 or Higher RCU Required
ALL	1065 1696	V8 CODES ONLY

WINDSTAR

Model No	Codes	Notes
ALL	0365	V8 CODES ONLY

ALL	0310 0584	
-----	-----------	--

WINDY SAM

Model No	Codes	Notes
----------	-------	-------

ALL	0584	
-----	------	--

WINTEL

Model No	Codes	Notes
----------	-------	-------

ALL	0742	V4 or Higher RCU Required
NR32WT10F	0742	V4 or Higher RCU Required

WORLD OF VISION

Model No	Codes	Notes
----------	-------	-------

ALL	0908 0918 0893 1317 1326 0905	V8 CODES ONLY
-----	-------------------------------	---------------

WORLDVIEW

Model No	Codes	Notes
----------	-------	-------

ALL	0073	
-----	------	--

X VIEW

Model No	Codes	Notes
----------	-------	-------

ALL	1219	V8 CODES ONLY
-----	------	---------------

XENIUS

Model No	Codes	Notes
----------	-------	-------

ALL	0689	V6 or Higher RCU Required
ALL	0662	V4 or Higher RCU Required

XIAHUA

Model No	Codes	Notes
----------	-------	-------

ALL 0726 V4 or Higher RCU Required

ALL 0037 0292 0440

XIANGHAI

Model No Codes Notes

ALL 0037

XIANGYANG

Model No Codes Notes

ALL 0292 0440

XIHU

Model No Codes Notes

ALL 0292 0440

XINAGHAI

Model No Codes Notes

ALL 0440

XINGFU

Model No Codes Notes

ALL 0037

XINGHAI

Model No Codes Notes

ALL 0292

XINGYU

Model No Codes Notes

ALL 0037

XLOGIC

Model No	Codes	Notes
ALL	0726	V4 or Higher RCU Required

XORO

Model No	Codes	Notes
ALL	1271 1224 1245	V8 CODES ONLY

XRYPTON

Model No	Codes	Notes
ALL	0065 0584	

YAMADA

Model No	Codes	Notes
ALL	NO CODES AVAILABLE	

YAMAHA

Model No	Codes	Notes
ALL	0825	V8 CODES ONLY
ALL	0065 0678 0311	

YAMISHI

Model No	Codes	Notes
ALL	0310 0246 0065 0584 0245	

YINGGE

Model No	Codes	Notes
ALL	0037	

YOKAN

Model No	Codes	Notes
ALL	0065 0584	
YOKO		

Model No	Codes	Notes
ALL	0398 0292 0065 0244 0459 0037 0245 0246 0584 0275 0449 0367	
YONGGU		

Model No	Codes	Notes
ALL	0037	
YORK SOUND		

Model No	Codes	Notes
ALL	0065	
YORX		

Model No	Codes	Notes
ALL	0246	
YOUSIDA		

Model No	Codes	Notes
ALL	0037	
YUHANG		

Model No	Codes	Notes
ALL	0037	
ZANELA		

Model No	Codes	Notes
----------	-------	-------

ALL	0266	
-----	------	--

ZANUSSI

Model No	Codes	Notes
----------	-------	-------

ALL	0391 0245 0234	
-----	----------------	--

ZENITH

Model No	Codes	Notes
----------	-------	-------

ALL	1937	V6 or Higher RCU Required
-----	------	---------------------------

ALL	0652	V4 or Higher RCU Required
-----	------	---------------------------

ALL	0065 0045	
-----	-----------	--

R35A09	0652	V4 ONLY RCU
--------	------	-------------

TVA1321	0652	V4 ONLY RCU
---------	------	-------------

ZENOR

Model No	Codes	Notes
----------	-------	-------

ALL	0367	
-----	------	--

ZHUHAI

Model No	Codes	Notes
----------	-------	-------

ALL	0037 0402	
-----	-----------	--

ZONDA

Model No	Codes	Notes
----------	-------	-------

ALL	0726	V4 or Higher RCU Required
-----	------	---------------------------

ZX

Model No	Codes	Notes
----------	-------	-------

ALL	1936	V6 or Higher RCU Required
-----	------	---------------------------

ALL	0312	
-----	------	--